


# CORDLESS CELLULAR SHADES

INSTRUCTION



# INSTALLATION


Installing the Brackets


# OUTSIDE MOUNT: Position brackets above window opening. Remember to leave the brackets few inches away from each side of your window. Spread them out evenly by having same distance from each side of the window. NOTE:

Make sure the shade is level


# INSIDE MOUNT:


Position **brackets** (a) along the top of the window opening in the desired location. Remember to leave few inches away from each side of your window.






Remove the wrap and install the **headrail endcaps (C)**, and **bottomrail endcaps (D)** on each end.







#### Mount Shade on Brackets

Install the headrail by hooking the front of the **bracket** (A) and push shade towards back of **brackets**, in a rolling motion, until clicks place.







#### Quick Reminders

$\mathbf{A}$	
$\Box$	

Please allow 24 hours for your shade to drop to its actual height when first installed due to the nature of the fabric.

For cordless cellular shade, it is recommended to operate every 5 to 7 days because if the fabric is in long-term stationary position, that will cause the operation to not function smoothly (raising and lowering), especially for opaque fabrics.

#### **Chicology Ready-Made Blinds Warranty** Limited One Year Warranty from the Date of Purchase

#### What is Covered:

All of our blinds are warranted against manufacturer defects in materials or workmanship provided that you are the original purchaser of the product, and the product was installed according to our instructions.

#### What is Not Covered:

- Normal wear and tear
- Consumer damages caused by accidents, alternations, abuse of the product, exposure to salt air, misuse, or damages from pets or insects.
- Damages resulting from removal and reinstallation in the same or any other window or application, or failure to follow instructions, such as measurement, installation, cleaning, and ma intenance.
- Any products that, with the passage of time, has yellowing or cracking of plastic parts.
- Wrong measurements are not covered by the warranty and are not refundable.

### **To Report Shipping Damages:**

If damage occurred during shipping, please email and call us immediately and report within 14 calendar days or else you may be denied for your damaged product.

## To Obligations to the consumer:

The obligations of Chicology are limited to the repair or replacements of parts or products found to be defective. Chicology will determine if the product is defective or not and may replace the product. If the product is found to have manufacture defects, we will repair or replace the product. Colors do vary from lot to lot, and may not match original product exactly. Discontinued items will be replaced with the most current product of the same price.

#### Your Rights under State law:

This limited warranty gives you specific legal rights, and you may have other rights, which vary from state to state.

#### **Defective Product:**

If you believe your shade has a manufacturing defect, please email and call us.

#### **Need Further Assistance?**

Website:	www.chicology.com/help
Email:	support@chicology.com
Phone:	1 (866) 999-6188

# **Need Further Assistance?**

We stand by our products and we're here to help. Call or email us, and expect a reply within 1 business day.

Visit our website for how-to videos and FAOS.

Website: www.chicology.com/help Email: support@chicology.com 1 (866) 999-6188 Phone: Mon-Fri 8AM to 5PM (PST) Hours:

Chicology Home ( Chicology Home

p Chicology Home Chicology Home

