


# CORDLESS VERTICAL BLINDS INSTRUCTIONS




## PREPARATION

### 1 Check the Hardware

- A** Head Rail x 1
- B** Wand x 1
- C** Valance Returns x 2
- D** Valance Clips x 3
- E** Valance Corners x 2
- F** Louvers x 25
- G** Mounting Bracket x 3
- H** Mounting Bracket x 3
- I** Mounting Screws x 6
- J** Wall Anchors x 6
- K** Valance x 1


### 2 Prepare Tools



### 1 Position Blinds


#### OUTSIDE MOUNT:

Place a light pencil mark on the front of the **headrail A** 7 inches in from each end. Hold the **headrail** up to the sliding door at the height of the pencil marks on the wall. Center the **headrail** over the top of the sliding door and use the pencil marks on the **headrail** to make two more pencil marks on the wall.



#### INSIDE MOUNT:

Place a light pencil mark on the front of the **headrail A** 7 inches from each end. Hold the **headrail** up inside the sliding door casing and place pencil marks on casing, directly in line with the **headrail** marks.




**NOTE:** The third bracket should be evenly spaced between the two outer brackets.

### 2 Mount Brackets


#### OUTSIDE MOUNT:

You may need to assemble the brackets for the outside mount. Place **mounting brackets H** at pencil mark and secure in place with **mounting screws I**.




#### INSIDE MOUNT:

You may need to disassemble the brackets for the Inside Mount. Only the metal clip will be used for the inside mount method. Align front of the metal clip with the pencil mark. The hole for the clip must be at least 2 in. away from the sliding door or wall to allow for full **louver F** rotation. Fasten the metal clip to the sliding door frame with the **mounting screw I**.




### 3 Hang Headrail

The **headrail A** is reversible depending on which side you want to have the **louvers F** stacked and where the **wand B** controls. Center the **headrail** under the **mounting bracket I** and snap into position.




## 4 Install Louvers


Insert **louvers F** in open position. Hold the **louver** securely at the top and gently push upward into the carriage until it snaps into place as shown. Repeat for each **louver**, and be sure they are all facing the same direction.




## 5 Install Valance



Snap the **valance clips G** onto the **headrail A**.



Snap the **valance clips G** near the edges of the track, while placing one **valance clip G** on the center of the track.




Trim the **valance returns C** to the desired length. Once trimmed, place the **valance return C** into the **valance corner E**.

## Quick How-to-use Guide

To tilt **louvers F**: Rotate the wand until **louvers** are in desired position. If **louvers** become misaligned, simply turn the **louver stems** in place by hand.

To open and close blind: Use the wand to traverse the **louvers** to the desired position.



## Questions

EMAIL  
support@chicology.com

PHONE  
866-999-6188

HOW - TO  
www.chicology.com/how-to

HELP  
www.chicology.com/help



## Chicology Ready-Made Blinds and Shades Warranty

Limited One Year Warranty from the Date of Purchase

### What is Covered :

- All of our shades are warranted against manufacturer defects in materials or workmanship provided that you are the original purchaser of the product, and the product was installed according to our instructions.

### What is Not Covered :

- Normal wear and tear.
- Consumer damages caused by accidents, alterations, abuse of the product, exposure to salt air, misuse, or damages from pets or insects.
- Damages resulting from removal and reinstallation in the same or any other window or application, or failure to follow instructions, such as measurement, installation, cleaning, and maintenance.
- Any products that, with the passage of time, has yellowing or cracking of plastic parts
- Wrong measurements are not covered by the warranty and are not refundable.

### To report shipping damages :

If damage occurred during shipping, please call 1 (866)999-6188 immediately and report within 14 calendar days or else you may be denied for your damaged product.

### Obligations to the consumer :

The obligations of Chicology are limited to the repair or replacements of parts or products found to be defective. Chicology will determine if the product is defective or not and may replace the product. If the product is found to have manufacture defects, we will repair or replace the product. Colors do vary from lot to lot, and may not match original product exactly. Discontinued items will be replaced with the most current product of the same price.

### Your Rights under State law :

This limited warranty gives you specific legal rights, and you may have other rights, which vary from state to state.

### Contacting us :

If you believe your shade has a manufacturing defect, please call 1 (866)999-6188