


Installation Instructions for Cat-Proof Existing Fence Conversion System

If you have a unique application (masonry walls, PVC Fence, etc.) feel free to call us 9am-5pm Eastern Time Monday through Friday or email any questions to info@purrfectfence.com Pictures are helpful!



x1 Roll of Fence (4' x 100')

*Folded in half height-wise



x12 Arms




x12 Arm Plates



x12 Set Screws



x2 Arm to Wall Straps




1 Bag of 100 Zip Ties



1 x Hex Wrench

1 Measure Arm height






6' or Higher

From the ground to the highest point of the arm as shown here

2 Install Arms

(Mounting hardware not included)

Note: For wooden fences, Galvanized Wood Screws will work best. For cement walls, pre-drill holes and use cement screws. Use U-Bolts for chain link fences.




Corner Post

Set at as close to 45° as possible.

Note: See back for more on corners as well as Gates.

3 Use Zip Ties to attach fence to tips of all Arms




Important! The Fence should be attached to the INSIDE of the Arms, not the outside.

Unroll Fence from Arm to Arm

Note: Zip Tie the fence to the tips of ALL the arms first, so that the roll of fence ends up dangling from the tips of the arms.

4



Attach mesh to fence.

Where to Attach Ties




Start at the middle arm of a section, and zip tie the mesh twice on the top bar before the spring and twice on the angled portion after the spring (see left). Then, from the middle Arm, do the same on the Arm to one side of the first Arm, then the arm to the other side of the center Arm. Work your way out in this manner until you have completed the side. Repeat for the other sides. **DO NOT PULL THE MESH TOO TIGHT- ANY SAG CAN BE FIXED AFTER THE FENCE IS INSTALLED.**

On a wood fence, use a Staple Gun to attach the mesh onto the wooden fence. For a Vinyl existing fence, we suggest using our "PVC Wall Kit" (sold separately). For Brick or Cement walls, you can bolt a horizontal wood runner to the wall and staple the fence to it or attach the mesh in some other manner to the wall.


Installation Tips

Installing Fence On Corners


Run Fence to end, past the Arm. Zip Tie Fence to Arm.




Cut the fence 4 squares past the Arm.



Zip Tie first section to the Arm. Attach second side with Ties and continue installing the fence.




Installing an inside corner using 1 plate and 2 Arms




Outward Opening Gate Installation

Note the collar used for each plate below (A,B,C,D)



Inward Opening Gate Installation



Note the collar used for each Arm above.

Set Arms "B" and "C" above Arms "A" and "D" so that when the gate opens outward the Arms on the gate ("B" and "C") will pass ABOVE the fence material and Arms ("A" and "D") on either side of the gate. Test opening the gate before you add the Fence material to be sure that the Arms do not hit each other, preventing the gate from opening. Cut the fence between Arms "A" and "B" as well as "C" and "D".