



# Lunar

**ASSEMBLY INSTRUCTIONS**





**We are so thrilled you chose to spend every night on a Lunar!**

We know how excited you must be to hop in this thing and start binging your favorite Netflix shows, so we created this instruction manual to get you there quicker!

There are a couple of parts and pieces to this thing, so first let's make sure you have everything you need.



# You should have:

## Hardware:

- 21 X Self Tapping Screws
- 21 X Rubber Feet
- 6 X Long Feet
- 2 X Middle T Feet
- 40 X Machine Screws
- 4 X Small & Tall Corner Brackets
- 8 X Rubber Support Pads
- 2 X Single Brackets
- 6 X Machine Bolts
- 4 X Corner Angle Brackets

## Electronic Do-dads:

- 1 X Bluetooth Power Adapter
- 1 X Bluetooth Speaker
- 1 X Massage Power Adapter
- 1 X Massage Remote
- 1 X USB Lamp

## Sections:

- 1 X Headboard
- 1 X Chase Lounge
- 1 X Chase Lounge cushion
- 1 X Footer Bench
- 1 X Bookshelf Frame
- 1 X Box Spring
- 1 X Footboard
- 2 X Desk Stools

## Tools You Will Need:

- 1 X Phillips Screw Driver (Medium)
- 1 X Flat Screw Driver (Medium to Large)
- 1 X Adjustable Wrench



## STEP 1.

Begin by making sure you have a clear space to work with all of the items unboxed.

*\* **PRO TIP:** We recommend building over carpet or putting a cloth down to avoid your bed getting scratched*

## STEP 2.

Start by flipping over your Headboard, Chase Lounge, Footer Bench, Footboard, and Bookshelf Frame so that the bottom is facing up.

## STEP 3.

Pull out your Self Tapping Screws along with the Rubber Feet, and finally a Phillips head Screwdriver (Not Supplied).




## STEP 4.

Begin by using the self-tapping screws to secure the feet into the bottoms of all the sections following the pattern for each outlined here:

Key:

 = SECTION  
 = FEET





## STEP 5.

After all of the feet have been screwed on, it's time to work on supporting the box spring. For this you will need:


- **6 X Long Feet**
- **2 X Middle T-Feet**
- **6 X Machine Screws,**
- **4 X Machine Screws and Machine Bolts**



## STEP 6.

Use the following Diagram to help bolt the legs onto the box spring.


\* Note that the 2 Middle T Feet go in the middle of the frame and make use of nuts to secure them





## STEP 7.

Now it's time to get the bed bolted together.




Align all of the pieces to the following configuration and bolt in the Angle Brackets in each corner using the lower set of bolt holes in each section.

\* Note we've found it helps to have a friend to hold the pieces together while you bolt them up!



## STEP 8.

You will now bolt the Small & Tall Corner Brackets in the upper corner bolts in each corner, right above where you just installed the Angle Brackets.






## STEP 9.

Now Stick the Non-Slip Rub Pads onto the flat surface of the corner brackets, this will prevent your box spring from squeaking on the corners and ensure it stays in place.


**\*PRO TIP-** Use some rubbing alcohol on the corner brackets to make sure they are free of debris, then dry before applying the pads.






## STEP 10.

Now you will bold the single brackets at either end of the bed. These go in the middle and inside of the headboard and footer board.







## STEP 11.

Finally, Drop your box spring into the bed, slide the Footer Bench up against the Footer Board section of the bed.



## STEP 12.

Finally, plug the massage remote, Bluetooth Speaker, and power unit into their corresponding adapters.

**\*PRO TIP-** Congratulations. You did it. Take a break, sit back and enjoy :)





 Lunar