

WHELEN AEROSPACE TECHNOLOGIES

Phone: (860) 526-9504 Internet: www.flyWAT.com

Sales/Service e-mail: info@flyWAT.com

Installation Guide/ICA: Model 7192100 P/N: 01-0771921-00

LED Hydraulic Inspection Light Assembly

MARNING: This product can expose you to chemicals including Lead which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

SPECIFICATIONS:

CONTINUED AIRWORTHINESS: The hydraulic inspection light is designed with 7 white LEDs. If one or more LEDs fails, the unit may be replaced at the discretion to the operator.

Note: To reduce eye strain, use an optical filter such as dark glasses or a blue covering dome during LED inspection.

Inspect the lens. If there is excessive scratching, pitting, discoloration or cracking the unit may be replaced at the discretion of the operator.

PERIODIC INSPECTIONS: An annual inspection shall be performed unless the OEM specifies a shorter interval.

INSTALLATION PROCEDURES: The following information provides guidelines for the installation of the WAT LED Hydraulic Inspection light. Please refer to the OEM manual for your aircraft for specific removal and installation instructions.

- Using the mounting detail information provided, prepare the aircraft for means to secure the light assembly.
- Connect the light input leads. Connect the power lead to an appropriately sized breaker. Connections to be in accordance with FAA approved methods.
- 3. Using the appropriate hardware, install the light to the aircraft. Insure that all leads are clear of any obstructions and secured as required.
- 4. Place the light switch in the ON position and verify proper operation of the WAT Light.

PARTS LIST

- 1 Screw 2-56 X 1/4 P82FHMS SS
- 2 Retainer P/N 19-150994-001
- 3 Washer, #10 Flat .200" ID, .437" OD, .035" Thick
- 4 Washer, #10 Flat .631 X .060 THK/SS
- 5 Screw 10-24 X 3/8 SKTHEAD CAP SS

Dimensions: mm (inches)





