



13000 Temple Ave. City of Industry, CA 91746

Tech line (626) 968-5147 Main line (800) 237-7560
www.dcsports.com

CSB1409
Carbon Steel CS-2 Rear Strut Tower Bar
INSTALLATION INSTRUCTIONS

2013-up Scion FRS-Subaru BRZ / 2008-up Subaru WRX ALL

**READ INSTRUCTIONS THROUGH COMPLETELY BEFORE BEGINNING
INSTALLATION.**

**IF YOU ARE NOT COMFORTABLE AND/OR FAMILIAR WITH THESE INSTRUCTIONS, PLEASE
REFER THIS INSTALLATION TO A QUALIFIED PROFESSIONAL.**

1. Remove rear spare tire trunk panel.
2. Remove or push up and out of the way, both the left and right side plastic shock tower panels from each side of the trunk.
3. With the car set on the ground, remove the two (2) 10mm shock nuts from the left side shock tower and two (2) 10mm shock nuts from the right side shock tower. Set these nuts aside as they will be re-used.
4. Install the DC Sports Carbon Steel Strut Tower Bar by sliding the strut bar pad over one side of the shock tower studs and then over the other side shock tower studs.
5. Re-install the two (2) original 10mm nuts to the left side shock tower studs and the two (2) original 10mm nuts to the right side shock tower studs. Tighten all four (4) 10mm nuts (Torque: 6.0 kg-m, 43 lb-ft).
6. Optional: Re-install or push back into place the rear side panels. The rear spare tire trunk panel can be cut so that they can be re-used. If re-used, CAREFULLY cut the plastic panels where necessary so that it can slide under the DC Sports Carbon Steel Strut Tower Bar. If this option is skipped then the spare tire panel will not be reused.
7. **RE-CHECK ALL YOUR WORK.**

PARTS LIST

Quantity	Part Number	Part Description
1	CSB1409	Carbon Steel rear upper strut tower bar
2	DCS1008	DC Sports decals

THANK YOU FOR CHOOSING DC SPORTS