



SINGGATE DOOR LOCK **FR001**

6 UNLOCKING METHOD

- 1 2 3
- 4 5 6
- 7 8 9
- * 0 #
- Fingerprint icon
- Card icon
- APP icon
- Key icon
- Person icon

+

DOOR VIEWER

- Snapshot to APP icon
- View Outside from Indoor icon



2 YEARS WARRANTY ON-SITE



1. Adding Master Password when Initial Use/ Enter Digital Setting

Step 1	Step 2	Step 3	Step 4
Press on "*" and then "#" to enter setting mode.	Enter a 6–8-digit password and press on "#" to confirm	Enter the same password again and press "#" to confirm. You will be sent into the setting mode	Press "*" to exit setting mode

2. User Manage (Adding Users/ Admin)

Step 1	Step 2	Step 3
Press on "*" and then "#" to enter setting mode	Verify Admin and press "1" Add User and you will see the following options: 1. Add User 2. Add Admin	Press "1" or "2" from Step 2, The system will prompt you to Enter Unlock Information You may use the following options to register: 1. Add Fingerprint 2. Add Password 3. Add Card 4. Add Wi-Fi Unlock



Step 4

(1) Add fingerprint

The user places his finger on the fingerprint sensor and the voice prompt "please press your finger again", the user places the same finger on the sensor. The voice prompt "Successfully added, can be added continuously. To exit, press the "*" key", the user can continue to add.

(2) Add password

Enters a 6 to 8-digit password and press the "#" key to confirm, the voice prompt "Please enter the same password again", enters the same password again and confirm. Voice prompt "Added successfully"

(3) Add card

The user brings the card close to the antenna receiving area, and the voice prompt "Add successfully"

(4) Add remote control (USmartGo must be installed into your phone in order to use this function)

The user presses any key of the remote control that needs to be added, and the voice prompt "add successfully"

3. User Manage (Deleting User)

Step 1	Step 2	Step 3
Press on "*" and then "#" to enter setting mode	Verify Admin and press "2" Delete User and you will see the following options: 1. Verify Delete 2. Delete by ID	1. Verify Delete The voice prompt "Please verify the user to be deleted", the user can enter the password, fingerprint, card, or remote control to be deleted. If the user exists in the system, the voice prompt "Delete successfully", if the user does not exist, the voice prompt "Operation failed" 2. Delete by ID The voice prompt "Please enter the user number to be deleted", the user can enter a three-digit user number, such as "001". If the user exists in the system, the voice prompt "Delete succeeded", if the user does not exist, the voice prompt "Operation failed"



4. System Setting (Time and Date Setting)

Step 1	Step 2	Step 3	Step 4
Press on "*" and then "#" to enter setting mode	Verify Admin and press "3" System Setting	Press "1" Set Datetime and enter the details in the following format: YY : MM : DD HH : MM	Press "#" to confirm and Press "*" to exit setting mode

5. System Setting (Disable and Enable Authentication Setting)

Step 1	Step 2	Step 3	Step 4
Press on "*" and then "#" to enter setting mode	Verify Admin and press "3" System Setting	Press "3" Function Setting and You will see the following options: 1. Network Configuration 2. Double Authentication Setting 3. BarSet [ON]	Press "2" on Step 3 and you will see the following options: 1. Disable 2. Enable Once done, press "*" to exit setting mode



6. System Setting (Restore Factory Setting/ Factory Reset)

Step 1	Step 2	Step 3
Press on "*" and then "#" to enter setting mode	Verify Admin and press "3" System Setting	Press "4" Restore and Press "#" to confirm

7. User number query

Step 1	Step 2	Step 3
Press on "*" and then "#" to enter setting mode	Verify Admin and press "4" Language and Record and you will see the following options: <ol style="list-style-type: none"> 1. Storage Info 2. Read Record 3. Language 4. Voice Set 	Press "1" from step 2 and you will see the following information: Admin: XXX User: XXX Phone: XXX



8. Language Settings


Step 1	Step 2	Step 3
<p>Press on “*” and then “#” to enter setting mode</p>	<p>Verify Admin and press “4” Language and Record and you will see the following options:</p> <ol style="list-style-type: none"> 1. Storage Info 2. Read Record 3. Language 4. Voice Set 	<p>Press “3” from step 2 and you will see the following information:</p> <ol style="list-style-type: none"> 1. Chinese 2. English









9. Voice Settings









Step 1	Step 2	Step 3
<p>Press on “*” and then “#” to enter setting mode</p>	<p>Verify Admin and press “4” Language and Record and you will see the following options:</p> <ol style="list-style-type: none"> 1. Storage Info 2. Read Record 3. Language 4. Voice Set 	<p>Press “4” from step 2 and you will see the following information:</p> <ol style="list-style-type: none"> 1. Enable Voice 2. Disable Voice





10. Connect to Wi-Fi (Please download USmart Go)

Step 1	Step 2	Step 3	Step 4
<p>Press on “*” and then “#” to enter setting mode</p>	<p>Verify Admin and press “3” System Setting</p>	<p>Press “3” Function Setting and You will see the following options:</p> <ol style="list-style-type: none"> 1. Network Configuration 2. Double Authentication Setting 3. BarSet [ON] 	<p>Press “1” on Step 3 and the system will start configuring</p>
Step 5	Step 6	Step 7	Step 8
<p>Press Account Registration to register for an account</p> 	<p>Please Register by Email</p> 	<p>Press Add Device</p> 	<p>Press OK to add a family</p> 

Step 9	Step 10	Step 11	Step 12
<p>Enter Family Name and press OK to proceed</p> 	<p>Press on Add Device</p> 	<p>Select Add Wi-Fi Device</p> 	<p>Once you have reached this page, go to Wi-Fi list on your phone (Refer to Step 13)</p> 
Step 13	Step 14	Step 15	Step 16
<p>Select the Wi-Fi name starting with CloudHome</p> 	<p>Press on Connect</p> 	<p>Ensure that the Wi-Fi has been Connected (No Internet Access)</p> 	<p>Return to the App and wait for a few second (As shown below)</p> 

Step 17	Step 18	Step 19	Step 20
<p>The app will start to search for Wi-Fi</p> 	<p>Please select your home Wi-Fi (Ensure it is 2.4 GHz)</p> 	<p>Ensure that the Wi-Fi name is correct and enter your Home Wi-Fi Password. Press Search Device to proceed</p> 	<p>The app will show Connecting Wi-Fi. Do wait for 20-30 seconds (Depending on Wi-Fi connection)</p> 
<p>Once it is successfully connected, you may see a photo as shown below. Press Finish to proceed</p> 	<p>Ensure that there is a Smart Lock Added under My Devices. Press on it to enter</p> 	<p>Under Smart Lock, you may see a photo as shown below. Do try using your password, card and fingerprint to unlock the door</p> 	<p>After using your password, card and fingerprint to unlock, you may see the records appeared as shown as the picture below</p> 







Step 25	Step 26
<p>Press on the Bell on the lock, You will receive a notification for Remote Unlock</p>  A notification titled "Request for remote unlock" is shown. It features a photo of a green smart lock with a blue bell icon. Below the photo, it displays "Device Name: Smart Lock", "Device ID: 2CCE02E13040", and "Family: 1". At the bottom, there are two buttons: "Ignore" (red) and "Unlock (37%)" (blue). A red arrow points to the bell icon in the photo. <p data-bbox="532 934 792 991">Device Name: Smart Lock Device ID: 2CCE02E13040 Family: 1</p>	<p>Enter your password to authorize Remote Unlock. The door will then be unlock</p>  A "Security verification" screen from the Smart Lock app. It has a title bar with "Smart Lock" and "8:55 AM". Below the title is a "Verify with security password" section with a text input field and a blue eye icon. A note below says "Please use account password if you forget security password" with a "Click to switch" link. A notification card for "Request for remote unlock" is visible. At the bottom is a numeric keypad and a checkmark button. <p data-bbox="841 688 1101 991">Smart Lock 8:55 AM Security verification Verify with security password Please use account password if you forget security password Request for remote unlock 1 2 3 4 5 6 7 8 9 0 @ # \$ % ^ & * () = + abc . / : ; ' ? , - =</p>



11. Door Viewer Setting


Camera Angle	Language	Date/Time
<p>Press and hold the Center button and then the Right button to enter setting mode. Press the right button twice and select Setup (⚙️)</p> <p>Select Camera Angle and you will see the following options:</p> <ol style="list-style-type: none"> 1. All Angle 2. Undeformed Angle 	<p>Press and hold the Center button and then the Right button to enter setting mode. Press the right button twice and select Setup (⚙️)</p> <p>Select Language and you will see the following options:</p> <ol style="list-style-type: none"> 1. 简体中文 2. 繁体中文 3. English 	<p>Press and hold the Center button and then the Right button to enter setting mode. Press the right button twice and select Setup (⚙️)</p> <p>Select Date/Time and enter the details in the following format:</p> <p>2021 / 01 / 02 18 : 52 : 48</p>

12. Change Username in Apps (USmart Go)




Step 1	Step 2	Step 3	Step 4
<p>Press on Smart Lock to enter</p> 	<p>Select on any records (password, IC Card or Fingerprint) as shown from the picture below</p> 	<p>Press on OK to proceed</p> 	<p>Enter your name Under User Name and press OK to proceed</p> 

Step 5

Use any methods to unlock the door and you can see **Username** on the record



13. Add members in Apps (USmart Go)

Step 1	Step 2	Step 3	Step 4
<p>Press on Menu on the top left-hand corner</p> 	<p>Select My Families to proceed</p> 	<p>Ensure that Your Account Name (Email address) is correct. Press on Add Family Member to proceed</p> 	<p>Ensure that your family member has already registered an account. Input His/her Email address and Name to proceed</p> 