





# 1. Adding Master Password and Enter Digital Lock Setting

Step 1	Step 2	Step 3
Tap on "*" and then "#" to enter setting mode	Enter a <b>6 digit password</b> and tap on "#" to confirm	Repeat the password and tap on "#" to confirm



## 2. User Manage (Adding Users)

Step 1	Step 2	Step 3	Step 4
Press on "*" and then "#" to enter setting mode	Verify Admin and press "1" User Manage	Press "1" <b>Create User</b> and you will see the following options:  1. Administrator	Press any of the options from step 3 and you will see the following options:  1. Enroll FaceID
		Normal User     Guest User     Coerce User	Enroll password     Enroll ID Card     Enroll Fingerprint

### Step 5

#### A: Enroll Face ID

(Voice Prompt: Please look at the camera)

Stand in front of the digital lock, and look at the camera, the face detector will auto scan and register. Until hear (Voice Prompt: Enroll Success)

### **B**: Enroll Password

Enter a 6-digit password and press on "#" to confirm. (Voice Prompt: Please enter again) Please enter the same 6-digit password again and press on "#" to confirm.

### C: Enroll ID Card

Place your RFID card | tag | sticker between 5 and 8 to register. Until (Voice Prompt: Enroll Success)

### D: Enroll Fingerprint

Place your selected finger on the fingerprint scanner and continuously the same position until (Voice Prompt: Enroll Success)



## 3. User Manage (Deleting User)

Step 1	Step 2	Step 3	Step 4
Press on "*" and then "#" to enter setting mode	Verify Admin and press "1" User Manage	Press "3" <b>Delete User</b> and you will see the following options:  1. Delete by ID 2. Delete by Type 3. Delete All	If you Press "2" under step 3, you will see the following options:  1. Clean Face ID 2. Clean Password 3. Clean ID Card 4. Clean Fingerprint

<sup>\*</sup>If all management users are deleted, users will not be able to enter the management menu, please exercise caution.

## 4. System Setting (Time Setting)

Step 1	Step 2	Step 3	Step 4
Press on "*" and then "#" to enter setting mode	Verify Admin and press "3"  System Setting	Press "1" <b>Time Setting</b> and enter the details in the following format:  YY: MM: DD HH: MM	Press "#" to confirm and Press "*" to exit setting mode

<sup>\*\*</sup>After operating "Delete All", any unlocking method can be unlocked, please proceed with caution



# 5. System Setting (Language and Voice Volume Setting)

Step 1	Step 2	Step 3	Step 4
Press on "*" and then "#" to enter setting mode	Verify Admin and press "3" System Setting	Press "2" Language and Volume Setting and you will see the following options:  1. Chinese 2. English 3. Volume Low 4. Volume High	Press "#" to confirm and Press "*" to exit setting mode



# 6. System Setting (Single Verify and Multiple Verify)

Step 1	Step 2	Step 3	Step 4
Press on "*" and then to enter setting mode	Verify Admin and press "3'  System Setting	Press "3" <b>Lock Setting</b> and You will see the following options:  1. Single Verify 2. Multiple Verify 3. Disable Verify 4. Anti-Pry	Press "#" to confirm and Press "*" to exit setting mode

# 7. System Setting (Body Detect)

Step 1	Step 2	Step 3	Step 4
Press on "*" and then "#" to enter setting mode	Verify Admin and press "3" System Setting	Press "4" Unlock Setting and Press "3" Body Detect [1]. Keep pressing "3" until Body Detect [0] to turn off	Press "#" to confirm and Press "*" to exit setting mode



# 8. System Setting (Restore Factory Setting/ Factory Reset)


Step 1	Step 2	Step 3	Step 4
Press on "*" and then "#" to enter setting mode	Verify Admin and press "4" System Query	Press "4" <b>Factory Reset</b> and Press "#" to confirm	Press "*" to exit setting mode




# 9. Connect to Wi-Fi (Please download USmart Go)

Step 1	Step 2	Step 3	Step 4
Press on "*" and then "#" to enter setting mode	Verify Admin and press "2" Remote Manage. You will see the following options:  1. Create Phone 2. Delete Phone 3. Create Remote 4. Delete Remote	Press "1" from step 2 and you will see the following options:  1. WIFI 2. AP	Press "1" and the system will show Add WIFI please wait
Step 5	Step 6	Step 7	Step 8
Press <b>Account Registration</b> to register for an account	Please <b>Register by Email</b>	Press Add Device	Press <b>OK</b> to add a family
Trottes Seq. □ 4 ℃ □ 1822  Login Account	Postrosing ☑ ☑ ☑ ☑  Account Registration	MENU No families ▼ ADD	MENU No families ▼ ADD
Login by phone Login by email  +65   Please input phone number	< phone Register by email >	My Devices Scenes	My Devices Scenes  Please add a family at first
⊕ Please input password   ☑ Auto Login	☑ Please input email	No Data	Cancel
Login  Forget password?  Account Registration	Next	+ Add Device	+ Add Device
















# 10. Door Viewer Setting

Setup mode	Language	Date/Time
Press the "OK" and then " " to enter setting mode. Press the right button twice and select Setup ( ) Select Setup Mode and you will see	Press the "OK" and then "  " to enter setting mode. Press the right button twice and select Setup ( ) Select Language and you will see the	Press the "OK" and then " > " to enter setting mode. Press the right button twice and select Setup ( ) Select Date/Time and enter the details
the following options:  1. Photo Mode 2. Video Mode	following options:  1. English 2. 简体中文	in the following format: 2021 / 01 / 02 18 : 52 : 48 YY/MM/DD




# 11. Change Username in Apps (USmart Go)

Step 1	Step 2	Step 3	Step 4
Press on <b>Smart Lock</b> to enter	Select on any records (password, IC Card or Fingerprint) as shown from the picture below	Press on <b>OK</b> to proceed	Enter your name Under User Name and press <b>OK</b> to proceed
MENU Singgate ▼ ADD  My Devices Scenes	Smart Lock MORE  Unlocked the door	Smart Lock MORE  Smart Lock of the same of this user?	C Edit User User Type Password User ID
Smart Lock Device ID: 2804F7836440	Unlocked the door Faseword 1 Dec 2, 2021 1059:06 AM Unlocked the door IC Caret 3 Dec 2, 2021 1058:50 AM Unlocked the door Faseword 1 Dec 2, 2021 1058:36 AM Only show records for the last 30 days.	Cancel  Unlocked the door IC Card 3	User Name Testing Please Enter Your Name





### 12. Add members in Apps (USmart Go)



### **Unlock Protection:**

**FaceID Protection:** Continuing to attempt the wrong password more than 4 times will activate the alert.

**Password Protection**: Continuing to attempt the wrong password more than 5 times will activate the alert.

**Fingerprint Protection**: Continuing to attempt the wrong fingerprint more than 10 times will activate the alert.

**RFID Protection**: Continuing to attempt the wrong RFID password more than 10 times will activate the alert.