

HEATED GEAR

PREMIUM HEATED INSOLE





USER MANUAL









Thank you for purchasing our battery powered Bluetooth Heated Insoles. To ensure optimal performance of your Bluetooth Heated Insoles, please carefully read through this user manual prior to using the garment.

To keep up with our latest product information, please take a few minutes to register your product at fieldsheer.com/product-registration
You can also find other great Fieldsheer® products at www.fieldsheer.com





Proprietary Fieldsheer® powered by Mobile Warming® technology is specially engineered for cold weather conditions. Mobile Warming®'s comprehensive heating technology keeps you warm and comfortable in all weather conditions. Our exclusive heating technology utilizes ultra-fine fiber elements powered by lightweight, rechargeable, Lithium-lon batteries. As heat builds, Mobile Warming® technology reflect and direct heat back towards the body ensuring that you stay warm. The combination of unique materials, construction techniques, and innovative design results in the most advanced heated gear available.

≺⊏	
`-	

Garment Care	4
Entretien du vêtement Cuidado de la prenda Battery use and Maintenance	15 27 <mark>5-6</mark>
Utilisation et entretien de la batterie Uso de la batería y mantenimiento Quick Start Guide	16-18 28-31
Guide de démarrage rapide Guía de inicio rápido Heat Ratings	19-20 32-33
Évaluation de la chaleur Potencias caloríficas Warranty and Legal	21 34 10-12
Garantie et mentions légales Garantía y aspectos legales	22-24 35-37



Refer to your garment care label for care details

- · Spot cleaning only. dry flat
- · Do Not Fully submerge in water
- · No bleach, iron and wring
- · Fully dry before turning on.
- \cdot Fully charge the battery every 3-6months.
- \cdot Turn off in case of excessive temperature and when not in use.



Mobile Warming®'s powerful lithium-ion battery technology was designed and engineered to provide you with safe and reliable power, allowing you to be warm and comfortable. Please follow the instructions below to optimize your lithium-ion battery

USB CHARGING BATTERY

BATTERY USE

To charge your battery, use the supplied micro-USB cable. Connect the USB end to your computer or any USB powered source like the USB wall adaptor included with your phone or tablet





Do not use your heated insole if you notice a change of shape (lumps) due to internal battery over-heating when charging or if rust or corrosion is found. Use only with the charging adaptor provided with your product to charge your battery.



Never dispose of batteries in the garbage. Disposal of batteries in the garbage is unlawful under state and federal environmental laws and regulations. Always take used batteries to your local battery-recycling center.



This product contains chemicals known to the state of California to cause cancer and birth defects or other reproductive harm For more information visit www.P65warnings.ca.gov

IMPORTANT: This product is intended to be used by an adult and therefore it is sole responsibility of purchaser to follow detailed instructions and warnings. The Purchaser agrees to indemnify Manufacturer for any unintended use/misuse.

Avoid running Lithium-Ion batteries completely dead. This will result in performance problems and reduced battery life.

7. Avoid allowing your Micro-USB or DC Jack ports from being contaminated with debris that could interfere with operation. Suggest to check ports before each use.

Lithium-lon batteries by nature have diminished capacity output in extremely cold temperatures. We recommend keeping batteries away from extreme temperatures to maximize battery performance.

Do not allow Mobile Warming battery(s) to come in contact with water or liquids. If water or other liquids enter the battery interior, immediately unplug the battery from the garment. Do not use if you feel the battery is compromised.





- · Power off battery(s) if applicable
- · Fully charge battery(s) prior to storage(▮₩)



· Keep battery(s) in cool dry place out of direct sunlight



· Charge every 6 months to maintain battery life.

It is important to keep your battery charged (***)



· Do not store Mobile Warming batteries below - 4 F (- 20 C)(



- 1. To charge your heated insoles, plug the included dual Micro USB cable into the micro USB port on the side of each insole. Plug the USB-A to your computer or any USB powered source like the USB wall adaptor included with your phone
- 2. Charge for 4-6 hours. Red LED light Indicates charging. Blue LED light indicates fully charged



- 3. To turn heated insoles on or off press power button on side of insoles.
- 4. The LED light on side of insole indicates the current heating level.
- 5. Trim insoles to fit if necessary. Make sure not to trim insoles too short, you can use you existing shoe's soles as a template. Do not cut the inner most trim line, to avoid damage of the internal heating system.





6. Replace your shoe's existing insole with your heated insoles.

For more information or to see other products with Mobile Warming@ technology, please visit us at mobilewarming.com



7. MW CONNECTTM APP Available on the App Store





Allows you to control your Bluetooth® enabled garment with your mobile device.











Menu Icon

Add

Rename ex John's Jacket Complete

HEAT RATINGS

NOTE: Heat and time are estimated and may vary depending on conditions. Exposing battery to extreme temperatures may impact these estimates



 Insoles Heat Ratings 3.7v Power Ratinas Based on Fully Charged Battery



LIMITED ONE YEAR WARRANTY

Any damage caused to any Fieldsheer® products by misuse, abuse, improper care, accident, normal wear and tear, or the natural breakdown of materials over an extended period of time and use are not covered in this warranty. Any alterations or repairs (attempted or otherwise) performed on any Fieldsheer® products voids any and all warranties offered by Fieldsheer® for that particular item.

I FGAL

This device complies with part 15 of the FCC Rules and RSS-Gen of IC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.



If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- · Increase the separation between the equipment and receiver.
- · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- · Consult the dealer or an experienced technician for help.

CAUTION: To comply with the limits of the Class B digital device, pursuant to Part 15 of the FCC Rules, this device must be used with certified peripherals and shielded cables. All peripherals must be shielded and grounded. Operation with non-certified peripherals or non-shielded cables may result in interference to radio or reception.

MODIFICATION: Any changes or modifications of this device could void the warrantv.

Fieldsheer®, Mobile Warming®, Stay Warm, Stay Comfortable, MW connect™ and its related logos and images are property of Tech Gear 5.7 Inc and / or its affiliated companies