




# INSTALLATION INSTRUCTIONS

SKU: **SP-3167**

CENTRAL PLATES YAMAHA KODIAK 450 (2018+)



## SAFETY WARNING

Please **read and understand** all instructions and safety warning prior to install the product. Failure to do so could result in product damage, personal injury or even death.


- Stay alert! Watch what you are doing and use common sense while handling this product.
- Inspect product for damage prior to installation, do not use if product is in unsafe condition.
- Do not install product while under the influence of drugs, alcohol or medication.
- Always use safety equipment to prevent injuries. Approved face and eye protection must always be worn by the installer, as well as others in the work area.
- Do not over reach. Keep proper footing and balance at all times.
- Dress properly. Do not wear loose clothing or jewelry. Keep your hair, clothing and gloves away from moving parts.
- Keep your work area clean and well lit.

Item	Part No.	Description	Qty.
<b>COMPONENTS</b>			
Those items are shown on the first page.			
01	3167-01	Front Aluminum Central Plate	1
02	3167-02	Rear Aluminum Central Plate	1
<b>HARDWARE (3167-01)</b>			
Those items are included with each kit to install the front plate.			
03	A-1505	M6-1.00 Flange Lock Nut	3
04	A-2605	M6-1.00 x 20mm Hex Flange Bolt	2
05	A-2607	M6-1.00 x 25mm Hex Flange Bolt	2
06	A-2609	M6-1.00 x 30mm Hex Flange Bolt	2
07	A-4001	Rubber Strip / Adhesive Back, 1x2" x 1/8" Thick	4
08	B-5206	12mm ID. x 11/16" OD. x 3/8" Lg. Bushing	2
<b>HARDWARE (3167-02)</b>			
Those items are included with each kit to install the middle plate.			
04	A-2605	M6-1.00 x 20mm Hex Flange Bolt	6
05	A-2607	M6-1.00 x 25mm Hex Flange Bolt	1
07	A-4001	Rubber Strip / Adhesive Back, 1x2" x 1/8" Thick	8
09	A-4026	1-1/8" Steel Clamp / M6-1.00 Nut	4
10	B-5205	12mm ID. x 11/16" OD. x 5/16" Lg. Bushing	1

# INSTALLATION INSTRUCTIONS


## PREPARATION

- We recommend to standing the ATV up on its end, to be able to install easily the plate under the bike.
- Remove the factory skid plates.
- On the plates (or directly on the frame), stick the provided rubber strips. **Refer to the image below.**




## INSTALLATION (do not tight until all was fixed correctly)

1. Start with the middle of the front plate. Secure to the factory mounting points. Use (2x) M6x30mm bolts and (2x) 3/8" spacers (between the skid and the frame). **Refer to the schema below.**



2. Secure the front to the factory mounting points. Use (2x) M6x25mm bolts. Refer to the schema below.



3. Secure the rear to the factory mounting points. Use (2x) M6x20 bolts. Refer to the schema at step #1.


**NOTE:** Tight those two bolts now.

4. Install the rear plate to the frame, using the factory mounting points. See instructions & schema below.


a) Use (1x) M6x25mm bolt and (1x) 5/16" spacer (between the skid and the frame).

**NOTE:** Insert the bolt on the skid, then, the spacer on the bolt and connect to the frame.

b) Use (2x) M6x20mm bolts.



5. Using the provided steel clamps, secure the front to the frame. Refer to the schema below.



6. Once the 2 plates are correctly installed and aligned, tight all the bolts appropriately.

**NOTE 01:** Use 10mm socket to tight the M6 bolts.

**NOTE 02:** Tight the M6 bolts using about 7.8 ft/lbs.