



Handheld Vac 'n Seal

User Manual



Precision Appliance Technology, Inc.

Website: www.vestaprecision.com

TABLE OF CONTENTS

IMPORTANT SAFETY INFORMATION	3
VACUUM PACKAGING GUIDELINES	4
PRODUCT COMPONENTS.....	6
PRODUCT USAGE	7
OPERATING INSTRUCTIONS.....	8
TECHNICAL SPECIFICATIONS.....	9
LIMITED WARRANTY AND AFTER SALES SERVICE	10
Returns	10
Exchanges.....	10
Warranty Replacements.....	11
Shipping Charges	11
Damaged and Defective Items.....	12
What Does This Limited Warranty Not Cover?	12

IMPORTANT SAFETY INFORMATION

When using this electrical appliance, basic safety precautions should always be followed including:

1. Read and understand all instructions.
2. Operate the appliance indoors only on a dry, stable, hard surface.
3. Do not use the appliance near a heat source, on a hot surface, or in wet conditions.
4. To protect against electrical shock, do not immerse any part of the appliance in water or other liquid.
5. Unplug the appliance from the wall outlet when not in use and before cleaning.
6. Always unplug the device using the plug and never pull on the cord.
7. Do not operate the appliance if the cord or plug are damaged.
8. Do not operate the appliance if it malfunctions or is damaged.
9. Use this appliance for its intended use only.
10. Children should not use this appliance. When in use around children, close supervision by an adult is necessary and the appliance should be kept out of their reach.
11. This appliance is not intended for use by people with reduced physical, sensory or mental capabilities or who lack experience with cooking appliances.
12. Do not use an extension cord with this product.
13. Always use only food-grade, plastic pouches or pouch material, recommended by the manufacturer as suitable for cooking. Use only appropriately sized pouches and do not overfill the pouch.
14. This product is designed for household use only.

VACUUM PACKAGING GUIDELINES

- Follow all food safety regulations as outlined by the FDA at www.FDA.gov.
- Vacuum packaging is NOT a substitute for canning.
- Vacuum packaging is NOT a substitute for refrigeration or freezing.
- Vacuum packaging cannot reverse the deterioration of foods.
- Some fruits and vegetables may release gases, known as outgassing. When vacuum packaging these fruits and vegetables, outgassing can cause the vacuum to be gradually lost over time. Blanching or freezing before vacuum packaging helps prevent outgassing from occurring.

NOTE: Due to the risk of anaerobic bacteria, soft cheeses, fresh mushrooms, and alliums (garlic, onions, leeks, etc.) should never be vacuum packaged.

- It is critical that safe food handling and storage procedures are followed. You can reduce the growth of microorganisms by storing foods at temperatures below 40°F (4°C) or freezing at 0°F (-32°C). Freezing will not kill microorganisms but reduces their chance to grow. For long-term food storage, always freeze foods that have been vacuum packaged.

NOTE: Beef and other proteins may look darker after being vacuum packaged. This appearance is due to the removal of oxygen and is not an indication of spoilage.

- Before vacuum packaging liquids such as broths, soups, or stews, pre-freeze the item in a dish, bowl or ice tray until solid. Remove the frozen liquid and vacuum package before storing in your freezer until ready to use.

Food Storage and Safety Information


Storage	Foods	Typical Storage	Vacuum Packaging
Frozen	Meat	6 months	15-20 months
	Fish, Seafood	6 months	10-12 months
	Dried fruit, Coffee beans	6-9 months	18-24 months
Refrigerated	Meat	2-3 days	12-13 days
	Fish, Seafood	2-3 days	6-8 days
	Cooked meat	2-3 days	10-14 days
	Eggs	2-3 days	30-50 days
	Vegetables	2-3 days	7-10 days
Dry	Bread	1-2 days	6-8 days
	Cookies	4-6 months	12 months
	Noodles	5-6 months	12 months
	Rice	5-6 months	12 months
	Flour	4-5 months	12 months
	Crackers	3-4 months	12 months
	Coffee	2-3 months	12 months
	Tea	5-6 months	12 months
	Powdered Milk	1-2 months	12 months

PRODUCT COMPONENTS




1. Main body 2. Start button 3. Indicator light
4. Vacuum nozzle 5. Sealing ring 6. Vacuum nozzle O-ring
7. Air outlet 8. Charging port

PRODUCT USAGE



Bottle Stopper



Zipper Bag with Valve



Vacuum Canister

OPERATING INSTRUCTIONS

Before first use, please charge the device using the USB cable provided.

1. Align the vacuum nozzle of the Handheld Vac 'n Seal with the valve on a zipper pouch, the valve on a vacuum canister, or the valve on the bottle stopper, pressing gently.

NOTE: When using a canister or bottle stopper, turn the knob to the "Vacuum" position.

2. Press and hold the Start button to pump the air from the desired container.
3. After reaching the desired degree of vacuum, release the Start button.
4. After the work is completed, store the vacuum packaged items.
Note: If using a canister or bottle stopper, turn the top knob to "Lock" before storing.
5. When the pump is insufficient, charge the device using the USB cable provided. The indicator light will glow red during charging and glow green when finished.

TECHNICAL SPECIFICATIONS

Rated voltage: 110-120 V~ / 220-240 V~

Rated frequency : 60HZ / 50HZ

Rated power: 3.3 W

Pump: Single pump

Pressure: -17.7in Hg/-600mbar

Size: 5.7x2.4x3.5in/145x61x90 mm

Weight: 0.6 lb./0.27 kg

LIMITED WARRANTY AND AFTER SALES SERVICE

Returns

If you are not fully satisfied, our products come backed with a 30 day, no questions asked, money-back guarantee. To be eligible for a full refund, you must:

- Have purchased your product in the last 30 days directly from Vesta Precision
- Have the original order number or email that was used during your purchase
- Email your request for your return and full refund

Full refunds can only be provided within 30 days of purchase directly from Vesta Precision. Devices purchased through resellers, retail partners, or other websites are not eligible for a return and full refund. Please consult their return policies for more information. We cannot provide a full refund for any damaged devices not covered under our limited warranty.

Exchanges

We provide products with a few different options. Retail exchanges are eligible within 30 days of original date of purchase. To be eligible for an exchange, you must:

- Have purchased your product in the last 30 days directly from the Vesta Precision
- Have the original order number or email that was used during your purchase
- Email us to request an exchange

Retail exchanges can only be provided within 30 days of purchase directly from Vesta Precision. Products purchased through resellers, retail partners, or other websites are not eligible for a retail exchange. Please consult their exchange policies for more information. We cannot provide a retail exchange for any damaged devices not covered under our limited warranty.

Warranty Replacements

Our products come with a 2-year limited warranty. Warranty replacements are eligible within 2 years of original date of purchase. To be eligible for a warranty replacement, you must:

- Have purchased the product within the last 2 years
- Have the original order number or email that was used during your purchase. If purchased through a reseller, retail partner, or other website, you must provide a copy of your original receipt
- Email us to request warranty service

Warranty replacements can only be provided within 2 years of original purchase date. We cannot provide a warranty replacement for any damaged devices not covered under our limited warranty.

Shipping Charges

Shipping charges incurred in connection with the return, exchange, or warranty replacement are paid for by Vesta via prepaid waybill issued by the support team.

Damaged and Defective Items

If you received a damaged or defective product, notify us immediately for assistance via phone, email, or web support. Please note that if we do not have an exact replacement for your unit, we will replace it with a similar unit of equal or greater value.

What Does This Limited Warranty Not Cover?

This limited warranty does not cover damages directly or indirectly arising or resulting from or during

- non-intended use of the product for any purpose not described in the user manual, and
- non-intended use with another product or other damage or loss suffered by such use or in combination with any other item
- accident, misuse, abuse, vandalism, power surges or acts of God (including lightning and other weather conditions)
- improper or inadequate maintenance
- unauthorized disassembly or modification
- repairs by an unauthorized service technician

WE ARE NOT RESPONSIBLE FOR AND THIS LIMITED WARRANTY DOES NOT EXTEND TO ANY CONSEQUENTIAL, INDIRECT, SPECIAL, INCIDENTAL OR PUNITIVE DAMAGES ARISING OUT OF OR RELATING TO THE UNIT. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation may not apply to you. This limited warranty is not transferable and is limited to the original purchaser.



Precision Appliance Technology, Inc.

Questions or Problems?

Contact support via

Website: www.vestaprecision.com

Email: support@vestaprecision.com

Phone: +18335045101 (US)

+442039363041 (EU)