



MODEL: L260
Medium Solar Wall Light |
Motion Sensor | 62LED | ABODE

For more information visit

hoselink.com.au

or call

1300 900 617

Cultivating **Connections**

 youtube.com/hoselink



User Manual

MODEL: L260
Medium Solar Wall Light |
Motion Sensor | 62LED | ABODE

HOSELINK[®]

Kit Contents

1 x Motion Sensor Solar Wall Light

Lighting Modes

1 Medium light mode (flashes once)

Light automatically comes on at dusk and off at dawn.
Motion sensor will not be active on this setting.

2 Dim light sensor mode (flashes twice)

Continuously emits a dim light (18 LEDs) from dusk until dawn,
with a bright light for 15-20 seconds when motion is detected.

3 Bright Sensor mode (flashes three times)

Light remains on standby mode until motion is detected
then a bright light will emit for 15-20 seconds.

Activate the Light

To activate the light, click the IO button on the side of
the light. The button with the M printed on it will allow
you to change between lighting modes.

Test by covering the solar panel completely to check
that the light comes on. The light is now ready for use.

Product Installation

STEP 1 Find a suitable location

Solar lights need access to direct sunlight for optimum
results; preferably 6-8 hours per day.

STEP 2 Install the light

Installation - Option 1

Using adhesive outdoor tape.

Adhere using Hoselink Outdoor Acrylic Double-Sided
Tape (SKU L100), sold seperately. Be sure to stick the tape
onto the stainless-steel plate on the back of the light.

Installation - Option 2

Using supplied hardware.

Use a 6mm drill piece for masonry installation. Once your
hole is drilled, gently hammer the plugs into place and

then secure the screws tightly. For timber, use a 3mm drill
piece without the plugs. Hang the light and enjoy.

Be sure to clean the solar panel periodically to maintain
optimal performance.

Specifications

Solar panel	5V / 1.2W
LED Lumens	220 lumens (bright light)
Light Temperature	6500 kelvins
Lithium Battery	2000mAh / 3.7V
Charge Time	8 hours
Working Time	Up to 90 hrs depending on light mode

NOTE: if the light does not turn on, this could be
due to the battery not being charged. Leave out in
direct sunlight for 6-8 hours and try again.