

	 Using the reset needle, press and hold reset but than 6s until the network indicator fiffifflashes, the the APP confifguration state. Enter the gateway.Please follow the picture below the decision of the picture below. 	device is under device to enter the device p w to finish as 14:45 ## 50 @	14:45 :::!! 56 E2	5.Click "Done" to enter the device page with home automation.
ZCSmart PIR MotionSensor	"Add subdevice→LED already blink,and the conne about 10-120 secondsto complete depending on condition. Cateway		Add Device Done Category (Manager 1998)	C Simet PR Motodemor
Scan this QR code 3 Method Two: 1. Make sure your MOES APP has successfully connected to a Zigbee gateway.	Ontine devices: 0 Added devices Ensure device is in pr (LED is blinking) If the LED is not strating gle device, here are some cannot	se reset the 2500 fee		Today
Na Sav The Saven State Saven Stream Stream State Saven State Saven State Saven State Saven Stream St	Senser have on the barrier for sea the barrier for sea the barrier to research of the search the barrier to research of the search the bad to search.	half die Hotet		Afternion 1445/35
All Devices ····	More divisor insur in LED already to ADS subday/star			
7	8		9	10

SERVICE

Thank you for your trust and support to our products, we will provide you with a two-year worry-free after-sales service (freight is not included), please do not alter this warranty service card, to safeguard your legitimate rights and interests. If you need service or have any questions, please consult the distributor or contact us.

Product quality problems occur within 24 months from the date of receipt, please prepare the product and the packaging, applying for after-sales maintenance in the site or store where you purchase; If the product is damaged due to personal reasons, a certain amount of maintenance fee shall be charged for repair.

We have the right to refuse to provide warranty service if: 1. Products with damaged appearance, missing LOGO or beyond the service term

2. Products that are disassembled, injured, privately repaired, modified or have missing parts

3. The circuit is burned or the data cable or power interface is damaged

4. Products damaged by foreign matter intrusion (including but not limited to various forms of fluid, sand, dust, soot, etc.)

RECYCLING INFORMATION

All products marked with the symbol for separate collection of waste electrical and electronic equip ment (WEEE Directive 2012/19 / EU) must be disposed of separately from unsorted municipal waste. To protect your health and the environment, this equipment must be disposed of at designated collection points for electrical and electronic equipment designated by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences for the environment and human health. To find out where these collection points ക are and how they work, contact the installer or your local authority.

WARRANTY CARD

Product Information

i loudot informatio	
Product Name	
Product Type	
Purchase date	
Warranty Period	
Dealer Information_	
Customer's Name	
Customer Phone	
Customer Address_	

16

Maintenance Records

Failure date	Cause Of Issue	F

Thank you for your support and purchase at we Moes, we are always here for your complete satisfaction, just feel free to share your great shopping experience with US.

*	*	*	

17

contact us first, we will try to meet your demand.

ye to enjoy your smart life	 How to Reset/Re-pair ZigBee code Using the reset needle, press and hold reset button for more than 6s until the network indicator flfflfflashes, the device is under the APP confifguration state. RECYCLING INFORMATION ① Storage: Products should be put in the warehouse where the temperature is between the range −10°C ~ +50°C, and the relative humidity <90%RH, indoor environment with no acid, alkali, salt and corrosive, explosive gas, flflammable matter, protected from dust, rain and snow. ② Security Information 1. Do not disassemble, reassemble, modify, or attempt to repair the product by yourself. Such products may cause electric shock, which may cause serious injury or death. 	 2. The battery of the product should be recycled, and it must be recycled or disposed of separately from household waste. Dispose of batteries in accordance with local environmental regulations. ③ Troubleshooting measures 1. Why does the device fail to link to the APP? a. ZigBee products work with the MPES/TUYA ZigBee gateway needed; b. Check whether the router connected to the gateway is connected to the external network. Ensure that the Wi–Fi signal of the gateway is good and try to connect the gateway again. c. Check whether the device is too far away from your gateway or other ZigBee devices to form a mesh network. Keep the ZigBee gateway and the ZigBee device close as recommended,where the distance should be moderate (less than 5 m). d. Check whether the device enters the network distribution mode. 	 Why doesn't the indicator flash after the device is power-on? a. The indicator will flash after the product is powered on. If not, please check whether the battery power is sufficient b. Check whether the device is in good contact and in normal APP configuration state before checking its indicator status. If the indicator does not blink yet, you may please contact our after-sales service. What to do if the smart linkage can not work between devices? a. Please confirm the device has been connected to the network which is under normal connection state. b. Please confirm whether you have updated your APP to newest version. c. Please confirm whether the smart scene set in the APP works with no conflict to other scenes. What if my device breaks down and doesn't respond for a long time? a. Hello,you may please try to reset the device by removing from he APP for new APP configuration.
	11	12	13

