

Model EP001: CHARTIERS POST

ANCHORING INSTALLATION INSTRUCTIONS

1. Obtain proper anchor bolts, nuts, washers and template from manufacturer.
2. Pour a 36" concrete footer, making sure to adjust depth to your local frost level and allow for the inlet supply. *Footer should be a minimum of 3" larger in diameter than the provided template.
3. Place ½ of each anchor bolt with threaded side up halfway into the concrete.
4. Place the template over the anchor bolts with each anchor bolt aligning through the four holes of the template.
5. Press the anchor bolts down into the concrete leaving approximately 2" of the threaded bolt above the concrete surface.
6. After situating to desired position, let concrete dry thoroughly.
***Do not attempt the next step until the concrete is thoroughly hardened.**
7. Remove the four nut covers from the base of the post.
8. Place the base over the anchor bolts and secure using one washer and one nut per bolt.
9. Apply the nut covers.
10. Place the cap on top of the base.
11. Slide the aluminum post down through the cap and the base.
12. Carefully slide the cap up and tighten the three set screws in the top of the base to secure the aluminum post in place.
13. Slide the cap back down and secure it to the base by tightening the three screws.
14. **For Gas:** With the coiled end at the top, slide the copper feedline down through the post, remove the access door from the bottom of the base (by removing the two screws on each side of the plate) to access the connections, and then replace it once all connections are made.
For Electric: Feed the wires from the main in through the inlet supply and up through the post to make your connections to the lamp at the top of the post.
15. For lamp installation, follow the installation instructions packed with the lamp.

