

# How to test your ATM Switch through the by-pass process

Whenever your pilot shuts off after releasing your control knob, it is usually a sign that the anti-tilt switch (also known as the ATM) is faulty.

The following pages include instructions to by-pass the ATM switch, for testing purposes ONLY.

**THIS TEST IS FOR DIAGNOSTIC PURPOSES ONLY**  
**NEVER RUN YOUR UNIT WITHOUT ENGAGING THE ATM SWITCH, THIS IS A SAFETY SWITCH TO SHUT OFF YOUR HEATER IN THE EVENT IT FALLS OVER**

# Bypassing the ATM

Step 1:

Remove the tank housing

---



\*before starting this process be sure to remove your propane tank\*

Remove all 4 screws  
There are 2 on the front and 2 on the back

**THIS TEST IS FOR DIAGNOSTIC PURPOSES ONLY**  
**NEVER RUN YOUR UNIT WITHOUT ENGAGING THE ATM SWITCH, THIS IS A SAFETY SWITCH TO SHUT OFF YOUR HEATER IN THE EVENT IT FALLS OVER**





## Bypassing the ATM

- Step 2

Remove the two lead wires from the ATM switch



**THIS TEST IS FOR DIAGNOSTIC PURPOSES ONLY**  
**NEVER RUN YOUR UNIT WITHOUT ENGAGING THE ATM SWITCH, THIS IS A**  
**SAFETY SWITCH TO SHUT OFF YOUR HEATER IN THE EVENT IT FALLS OVER**



## Bypassing the ATM

- Step 3

Connect the two female spade connectors, as shown below



Pull down the plastic from the metal spade connectors.



**THIS TEST IS FOR DIAGNOSTIC PURPOSES ONLY**  
**NEVER RUN YOUR UNIT WITHOUT ENGAGING THE ATM SWITCH, THIS IS A SAFETY SWITCH TO SHUT OFF YOUR HEATER IN THE EVENT IT FALLS OVER**





## Bypassing the ATM

- Step 4

Turn your heater on.

---

➤ If your Pilot stays on you will need a new ATM switch.

➤ To purchase a new ATM switch please visit our website

[www.azpatioheaters.com](http://www.azpatioheaters.com)



**THIS TEST IS FOR DIAGNOSTIC PURPOSES ONLY**  
**NEVER RUN YOUR UNIT WITHOUT ENGAGING THE ATM SWITCH, THIS IS A SAFETY SWITCH TO SHUT OFF YOUR HEATER IN THE EVENT IT FALLS OVER**