

J-TUBE INTAKE

2016-2019 Polaris RZR XP-Turbo
Installation Guide



PARTS LIST

×

- | | |
|---------------------------|------------------------|
| 1 J TUBE ASSEMBLY | 4 1" BAND CLAMPS |
| 2 MALE/MALE HOSE FITTINGS | 1 90-98MM T-BOLT CLAMP |
| 1 SCREW | |

PLEASE READ ALL DIRECTIONS BEFORE STARTING INSTALLATION

98200109


×

96030011


D

ATV
DRIFT

INSTALLATION INSTRUCTIONS



- 1 Remove the engine cover at the bottom of the cargo bed.
- 2 Cut and remove the band clamps that hold the two stock hoses (from the crankcase breather and blow off valve) to the stock J-tube.
- 3 Unplug the pressure sensor at the top of the stock J-tube.



- 4 Loosen the stock T-bolt clamps on the air filter housing and on the inlet of the turbo. The stock T-bolt clamp on the turbo inlet will be re-used.
- 5 Remove the stock J-tube.
- 6 Remove the pressure sensor from the stock J-tube. Install it into the bung of the Dynojet J-tube. Install the sensor into the bung oriented such that you are using the screw hole labeled with an "A". Use the supplied screw to secure it.



- 7 Install the Dynojet J-tube into the vehicle in-place of the stock J-tube. Use the supplied T-bolt clamp to secure the Dynojet J-tube to the air filter housing. Re-use the stock T-bolt clamp on the turbo inlet side of the tube.
- 8 Use the 2 male/male hose fittings and the 4 - 1" band clamps to secure the crank case breather hose and the blow off valve hose to the Dynojet J-tube.



- 9 Plug the wiring connector back on to the pressure sensor.
- 10 Replace the engine cover.

PUSH THE LIMIT

2191 MENDENHALL DRIVE, NORTH LAS VEGAS, NV 89081 - 800-992-4993 - DYNOJET.COM

© 2019 DYNOJET RESEARCH ALL RIGHTS RESERVED