
Cascade
Tanaro
Cavity Sliding
Unit Assembly
Instructions



# **Steps 1 2 3**





- 1 Check floor and ensure it is level then cut closing jamb to size.
- 2 Attach CDS-9212 overhead track to cavity frame.
- 3 Insert CDS-180 roller assembly into track.

# **Steps 4 5 6**

#### **Hanger Position**

Hangers must be inserted into overhead track prior to assembling unit






Step 5

Step 6


- 4 Fix closing jamb to CDS-9212 overhead track. Fit into place, ensuring it is plumb and square. Pack if necessary and secure to stud work.
- 5 Fit CDS-180 Roller Base Plate to door 80mm from each end.
- 6 Install door onto roller assembly.

## Steps 7 8 9 10 11




- 7 Using the spanner provided, adjust the **shaft** of the roller assembly to adjust door to required height.
- 8 Using the spanner provided adjust the **shaft nut** of the roller assembly to lock door into required position.
- 9 Install door into position and check operation before cladding.
- 10A Clad wall, ensuring fixings do not penetrate through rails.
- 10B Install pelmets if applicable.
  - 11 Fit CDS-112/118 Closing cap over Closing Jamb and CDS-35 Edge Reveal over Split Jamb and screw into positon.


#### **Pelmet Detail**



#### **Flush Head Detail**



### **Cross Section View**



Tanaro Cavity Unit To suit: 90/92mm Studs, 10/13mm plasterboard