

2-Way Shoe Stretcher

HFA111/112

KCT

Warning

- Make sure not to hold the long wooden block too tightly when rotating the black metal bar.
- Excessive tension when adjusting the stretcher can cause damage to both the shoe and the stretcher.

Imported by:

KCT Leisure
Glebe Farm,
Old London Road,
Copdock, Ipswich,
Suffolk, IP83JN,
United Kingdom

User Instructions

1. Remove the Shoe Stretcher and Black Adjusters from packaging.
2. Insert Shoe Stretcher into the shoe that you want to stretch.
3. Ensure that the short wooden block located at the heel of the stretcher is situated at the heel, inside the shoe.
4. If you want to stretch particular areas of the shoe even further, loosen the Shoe Stretcher and remove. Then insert the black adjusters to achieve a custom shape to stretch desired areas (See Fig. B) and perform steps 2 and 3 again.

Note: Rotate **clockwise** to expand the shoe stretcher, and **anti-clockwise** to contract the shoe stretcher. (See Fig. C)

Rotate the black plastic knob near the heel to stretch the shoe length-ways, and rotate the metal bar to stretch the shoe width-ways.




Fig. A




Fig. B




Fig. C