



# COBRA RUNNING BOARD

PART #: TAC-NWB-013

**FITS:** 2022-Up Nissan Pathfinder



60-120 min



Cutting Required



Drilling Not Required


## Torque & Tools

Fastener Size	Tightening Torque (ft-lbs)	Wrench Required		Allen Wrench Included	
			<input checked="" type="checkbox"/> 10mm		<input type="checkbox"/> 4mm
<input checked="" type="checkbox"/> 6mm	<input checked="" type="checkbox"/> 7-8.5		<input checked="" type="checkbox"/> 13mm		<input type="checkbox"/> 5mm
<input checked="" type="checkbox"/> 8mm	<input checked="" type="checkbox"/> 18-20		<input type="checkbox"/> 16mm		<input type="checkbox"/> 6mm
<input type="checkbox"/> 10mm	<input type="checkbox"/> 35-40		<input type="checkbox"/> 18mm		<input type="checkbox"/> 8mm
<input type="checkbox"/> 12mm	<input type="checkbox"/> 60-70				

## BEFORE INSTALLATION

REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. ASSISTANCE IS RECOMMENDED.

## Part List






8mm x 25 mm  
Hex Bolts



8mm Flat  
Washers



8mm Lock  
Washers



8mm Hex  
Nuts




6mm x 20mm T-  
Bolts



6mm Flat  
Washers



6mm Lock  
Washers



6mm Hex  
Nuts

**PLEASE NOTE THAT THE FOLLOWING PICTURES ARE BASED ON THE DRIVER SIDE INSTALLATION**

## STEP 1

Starting on the Driver/Left front of the vehicle, use pry tools to remove plugs and the cover on the bottom of the vehicle, (Fig 1)

FIG 1




(Fig 1) Use pry tools to remove the plastic cover

## STEP 2

Select the Driver/Left Front Mounting Bracket. Attach the Mounting Bracket to the **threaded stud** on the front location with (1) 8mm Flat Washer, (1) 8mm Lock Washer and (1) 8mm Hex Nut, (Figs 2—4). Do not tighten hardware.


Attach the Mounting Bracket to the **threaded insert** with (1) 8mm Hex Bolt, 8mm Lock Washer and (1) 8mm Flat Washer, (Figs 2—4). Do not tighten hardware.

FIG 2




(Fig 2) Driver/Left front mounting location

FIG 3




(Fig 3) Attach Driver/Left Front Mounting Bracket to the front mounting location

FIG 4



(Fig 4) Driver/Left Front Mounting Bracket attached

FIG 6




(Fig 6) Driver/Left center Mounting Bracket attached to the center mounting location

## STEP 3

Move along the body panel to the center mounting location, (Fig 5). Select the Driver/Left Center Mounting Bracket. Repeat **Steps 1 & 2** to attach the Bracket, (Fig 6). Do not tighten hardware.

FIG 5




(Fig 5) Driver/Left center mounting location

## STEP 4


Continue to the rear mounting location in front of the rear tire, (Fig 7). Select the Driver/Left Rear Mounting Bracket. Attach the Bracket to the (2) **threaded inserts** with (2) 8mm Hex Bolts, (2) 8mm Lock Washers and (2) 8mm Flat Washers, (Figs 8—9). Do not tighten hardware.

FIG 7




(Fig 7) Driver/Left rear mounting location

FIG 8




(Fig 8) Attach Driver/Left Rear Mounting Bracket

FIG 9




(Fig 9) Driver/Left rear Mounting Bracket attached to the rear mounting location

FIG 10



(Fig 10) Insert (6) T-Bolts into the bottom of the Running Board, (3) per channel

FIG 11



(Fig 11) Attach (1) Running Board to the (3) Mounting Brackets

## STEP 5

Select (1) Running Board. Insert (6) T-Bolts into the channels in the bottom of the Running Board, (3) per channel, (Fig 10). Attach the Running Board to the Mounting Brackets with (6) 6mm Flat Washers, (6) 6mm Lock Washers and (6) 6mm Hex Nuts, (Fig 11). Do not tighten hardware.

## STEP 6


Level and adjust the Running Board and fully tighten all hardware.



## STEP 7

Select the factory cover. Line up the cover to the factory mounting holes. Mark where the Center Mounting Bracket sits. Using a hacksaw or sharp knife, cut the cover to allow the Bracket to go through. **(Fig 12)**. Only cut a little at a time.

FIG 12



**(Fig 12) Cut the plastic cover for the Center Mounting Bracket**

## STEP 8

Repeat **Steps 1—7** to install the Passenger/Right Running Board.

## STEP 9

Do periodic inspections to the installation to make sure that all hardware is secure and tight.

### Attention

To protect your investment, do not use any type of polish or wax that may contain abrasives that could damage the finish.

Mild soap may be used also to clean the Running Boards.