


TETHER KIT INSTRUCTIONS

A note before we start: Do you really need a tether? Unless there is an obvious potential hazard near the zome (sliding glass door for example, or located in a busy commercial space), we recommend that you first use the zome for a couple of days without the tether to determine if you really need it. Often times, once the amplitude of the swing is known, owners opt to remove the tether.

Assembly Instructions:

- 1. Have the zome sit in the resting position, with the door facing the direction you desire.
- 2. Make a small mark on the ground directly below the center of the zome.
- 3. Measure about 15" to the right and left (as you are looking at the door) from this mark, and make marks for the D-ring brackets.
- 4. Mount the D-ring brackets to the ground with the appropriate screws. *Note:* Your location may require different fasteners than provided.
- 5. Install the guick link and shock cords to each D-ring bracket.
- 6. Attach the other end of the shock cords to the zome bottom metal grating. Locate the connection along this same centerline (back-to-front), and about 15" from the left-right center.



If you have any questions or encounter any problems with installation, please give us a call or send us an email. We are here to help!

The KODAMA Team