




# Near® Zigbee PIR Motion Sensor User Manual

## Product Description




## Network Setting

1. Power on the product.




Rotate the battery cover anticlockwise to open.



Remove the battery insulation film to power on the product, the red LED will flash slowly for self-checking.

2. Press the reset button for 5s and release, the green LED will flash for network setting.



Press the reset button for 5s then release.



Distribution network:



- Press the reset button for 5s-10s, the red LED is on, once red LED turns off, release the reset button, the green LED flashes, means ready for network setting.
- The green LED will be on for 5s then turns off to indicate network setting succeeds. If fails, the green LED is off.

3. Installation Instructions:


- (1) After powered on, the product will enter self-checking state and the red LED will flash for 60s.
- (2) After self-checking, the product enters test mode for 5 minutes. When it detects human motion, the red LED flash and sends an alarm signal.
- (3) During working status, press set button, the red LED flash once, then enter testing mode.
- (4) After test mode is completed, sensor will enter normal working state: Human detected - motion triggers sensor - red light comes on - information reported via notification / trigger smart scene. Motion will not be registered within 1 minute of detection, after which another minute is required for PIR motion sensor to refresh.

## Installation Instructions

1. Installation position: Install the product where **people** may be detected to cross. It is recommended that the product be about 2.2m above the ground, as shown in the following figure.



2. Product installation: Remove the protective film from the adhesive on the base and attach the base to the installation position. Mount the product to the base.




Remove the protective film from the adhesive on the base.

Mount the product on the magnetic base.

## 3. Attention

- (1) There should be no object **obstructing** the **detection** range of the **sensor**, so as not to affect the detection results.
- (2) If a structure (such as a wall) comes between the sensor and the Zigbee gateway, the wireless communication distance will be shortened.

(3) The installation position of the equipment should be far away from air conditioning, electric fans, refrigerators, ovens and other objects that cause temperature changes, and direct sunlight should be avoided.




### Technical Parameters

Wireless Technology	ZigBee
Working Voltage	DC 3 V (CR123A battery)
Transmission Frequency	2.4 GHz
Working Temperature	-10°C to +55°C
Undervoltage Alarm	Supported
Detection Radius	8 m
Detection Angle	90°
Installation Height	2.2 m
Dimensions	48.4 mm x 53.4 mm

### Toxic or Hazardous Substances or Elements of this Product

Component Name	Toxic or Hazardous Substances or Elements					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent chromium (Cr (VI))	Polybrominated biphenyls (PBBs)	Polybrominated diphenyl ethers (PBDEs)
LED	0	0	0	0	0	0
PCB	0	0	0	0	0	0
Cover and other components	0	0	0	0	0	0

This table complies with SJ/T 11364.  
 0: indicates that the toxic or hazardous substance amount contained in all homogeneous materials of a component does not exceed that stipulated in GB/T 26572.  
 X: indicates that the toxic or hazardous substance amount contained in at least one of the homogeneous materials of a component exceeds that stipulated in GB/T 26572.



### Warranty Certificate

Warranty policy:

1. If the product has quality problems within 7 days of the payment date, you can apply for a refund based on the invoice price or to replace with the same model or have it repaired..
2. If the product has quality problems within 15 days of the payment date, you can apply to replace the product with the same model or have it repaired.
3. If the product has quality problems within 12 months of the payment date, you can apply to have it repaired.

What is not covered under this warranty:

1. The product owner has no warranty certificate or the warranty service has expired.
2. Damage caused by improper use, maintenance, or storage
3. Damage caused by disassembly and repair without Tuya's authorization
4. Damage caused by force majeure
5. Normal discoloration and depreciation after the product has been used

### User Form

User information (Specify real information. Tuya promises to use the information only for after-sales services.)

Name \_\_\_\_\_

Phone number \_\_\_\_\_

Email \_\_\_\_\_

Zip code \_\_\_\_\_

Address \_\_\_\_\_

Product information

Name \_\_\_\_\_ Model \_\_\_\_\_

Color \_\_\_\_\_ Product SN \_\_\_\_\_

Service Return  Replace  Repair

Fault symptoms \_\_\_\_\_

Handling date \_\_\_\_\_

Maintenance personnel signature \_\_\_\_\_

### Vendor Form

User information (Specify real information. Tuya promises to use the information only for after-sales services.)

Name \_\_\_\_\_

Phone number \_\_\_\_\_

Email \_\_\_\_\_

Zip code \_\_\_\_\_

Address \_\_\_\_\_

Product information

Name \_\_\_\_\_ Model \_\_\_\_\_

Color \_\_\_\_\_ Product SN \_\_\_\_\_

Service Return  Replace  Repair

Fault symptoms \_\_\_\_\_

Handling date \_\_\_\_\_

Maintenance personnel signature \_\_\_\_\_