

USER MANUAL

MANUAL WINDING MOVEMENTS



zrhbrg.

MANUAL WINDING MOVEMENT

{<u>NO DATE</u>}



1 WEARING POSITION / WINDING POSITION

In this position you can wind your watch. Turn the crown clockwise until you feel a slight resistance. When you feel the resistance you should stop, otherwise you risk overwinding the watch and damaging the movement.

2 TIME SETTING POSITION

Pull gently on the crown until it moves outward with a click.

In this position you set the time of your watch. To do this, turn the crown im clockwise until you reach the desired time. Then push the crown back in the wearing position.



MANUAL WINDING MOVEMENT

{DATEJUST, NO QUICK SET}



1 WEARING POSITION / WINDING POSITION

In this position you can wind your watch. Turn the crown forward until you feel a slight resistance. When you feel the resistance you should stop, otherwise you risk overwinding the watch and damaging the movement.

2 TIME SETTING POSITION | DATE SETTING POSITION

Pull gently on the crown until it moves outward to the second position with a click.

In this position you set the time and date of your watch. To do this, turn the crown forward until you reach the desired time and date and then push the crown back in the wearing position.

{Please note, to change the date on this movement type, you must turn the time 24 hours forward. Never turn the time backwards on this movement to avoid damage.}



MANUAL WINDING MOVEMENT

{DATEJUST, WITH QUICK SET}



1 WEARING POSITION / WINDING POSITION

In this position you can wind your watch. Turn the crown forward until you feel a slight resistance. When you feel the resistance you should stop, otherwise you risk overwinding the watch and damaging the movement.

2 DATE SETTING POSITION

Pull gently on the crown until it moves outward to the second position with a click.

In this position you set the date of your watch. To do this, turn the crown forward until you reach the desired time. Then push the crown back in the wearing position.

3 TIME SETTING POSITION


Pull gently on the crown until it moves slightly outward to the third position with a click. In this position you set the time of your watch. To do this, turn the crown forward until you reach the desired time and then push the crown back in the wearing position.

{Never turn the time backwards on this movement to avoid damage.}



MANUAL WINDING MOVEMENT

{DAYDATE, WITH QUICK SET}



1 WEARING POSITION / WINDING POSITION

In this position you can wind your watch. Turn the crown forward until you feel a slight resistance. When you feel the resistance you should stop, otherwise you risk overwinding the watch and damaging the movement.

2 DATE SETTING POSITION

Pull gently on the crown until it moves outward to the second position with a click.

In this position you set the date of your watch. To do this, turn the crown forward until you reach the desired time. Then push the crown back in the wearing position.

3 TIME SETTING POSITION / WEEKDAY SETTING POSITION

Pull gently on the crown until it moves slightly outward to the third position with a click. In this position you set the time of your watch. To do this, turn the crown forward until you reach the desired time and then push the crown back in the wearing position.

{Never turn the time backwards on this movement to avoid damage.}

! TIP

First set the correct day of the week, the time and last the date.