

Mission and Shaker Style Day Bed Assembly Instructions

Contents: sizes vary depending on model ordered

- (A) = 2 bed ends
- (B) = 1 guardrail (75-7/8" or 80-7/8" long)
- (C) = 2 bed rails (75" or 80" long)
- (D) = 9 slats (twin = 40-1/4", double = 55-1/4" queen = 61-1/4" long)
- (E) = 8 connector bolts (70mm long)
- (F) = 8 cross dowels
- (G) = 18 wood screws
- (H) = 1 Allen key

Tools required:

- Slotted screwdriver
- #2 Robertson or Phillips screwdriver

(E) connector bolt (F) cross dowel (G) wood screw (H) Allen key



Please read all instructions before beginning

1. Assemble bed using 2 bed rails (C), 2 bed ends (A), 1 guardrail (B), 8 connector bolts (E), with 8 cross dowels (F). Refer to "Figure 1" for correct position of bed rail, bed end and hardware. Before tightening the bolts, insert the rear guardrail into the slots in the bed ends. Finish tightening the bolts.
2. Slide 9 slats (D), into bed rail grooves and secure each slat with 2 wood screws (G), using predrilled holes. Refer to "Figure 2". Position 1 slat 3" from each bed end and 7 evenly spaced in between. Ensure that the spaces between slats are less than 3 1/2".

