

QUESTION?

As a quality home gym supplier we are committed to your complete satisfaction. If you have questions, or find missing or damaged parts, we will guarantee your complete satisfaction through our authorized dealer service centers or our home office customer service department. Please call your local dealer for assistance or RSI at 800-990-5556 (9:00 AM - 5:00 PM). Our trained techanicians will provide immediate assistance to you, free of charge.

We stand behind our products. Every piece, every part of this BODYCRAFT strength training system is guranteed for as long as you own it. We will repair or replace anything that goes wrong.

Bodycraft is a division of Recreation Supply Inc. P. O. Box 181 Sunbury, OH 43074

BEFORE YOU BEGIN

Congratulations and thank you gor selecting the **BODYCRAFT LEG PRESS** \blacksquare strength training system. The **BODYCRAFT LEG PRESS** \blacksquare offers an impressive array of strength training exercises to develop every major muscle group of the body. Whether your goal is cardiovascular fitness, a shapely, toned body or dramatic muscle size and strength, the **BODYCRAFT LEG PRESS** \blacksquare will help you achieve the specific results you want.


For your safety and benefit, read this manual and the accompanying literature before using the **BODYCRAFT LEG PRESS** \blacksquare . Keep this manual for future \Box reference. If you have additional questions, please call your local **BODYCRAFT** \Box dealer or our customer service department at 800-990-5556 Monday through \Box Friday, 9 a.m. until 5 p.m. Eastern Time.


IMPORTANT SAFETY NOTES

There is a risk assumed by individuals who use this type of equipment. Before beginning this or any other exercise program consult your physician. This is especially important for individuals over the age of 35 or persons with pre-existing health problems. Recreation Supply, Inc. assumes no responsibility for personal injury or property damage sustained by or through use of this product.

- 1. This product must be assembled on a flat, level surface to assure its proper function.
- 2. Clean pads and frame on a regular basis. We recommend warm, soapy water. Do not use harsh or abrasive chemicals.
- 3. Inspect and tighten all parts before every use. Replace any worn parts immediately. Failure to do so may result in serious injury.
- 4. Keep children away from the BODYCRAFT LEG PRESS II at all times.
- 5. Keep your hands away from cables and pulleys during operation. Keep your hands away from moving parts other than the designated handles.
- 6. When adjusting the seat, make sure the spring pin is fully engaged. If not, the seat may slip and cause serious injury.
- 7. Make certain all cables are seated within the pulleys before every use.
- 8. Exercise with care to avoid injury.
- 9. If unsure about the proper use of the **BODYCRAFT LEG PRESS** II strength training system call your local BODYCRAFT dealer or our customer service department at 800-990-5556.


EXPLODED VIEW





STEP 1


- 1. Attach the Weight Base Connector (207) to the Base Frame (1) using two 3/8" X 3-1/8" Hex Bolts (230), four 3/8" Washers (238) and two 3/8" Nylon Nuts (241). Look for the sticker on the Weight Base Connector (207) to determine the correct orientation.
- 2. Attach the Long Leg Press Connector (205) to the Base Frame (1) using the existing two 3/8" X 3-1/8" Hex Head Bolts (88) and two 3/8" Washers (101) used to assemble the Cable Arm Assembly to the Xpress Base Frame. Remove the Nylon Nuts and discard. Thread the bolts into the threaded holes in the Long Leg Press Connector (205).



STEP 2

- 1. Attach the Leg Press Main Frame (202) to the Weight Base Connector (207) and the Long Leg Press Connector (205) using four 3/8" X 4" Hex Bolts (229), eight 3/8" Washers (238) and four 3/8" Nylon Nuts (241).
- Attach the Base Stabilizer (201) to the Leg Press Main Frame (202) using two 1/2" X 3-1/4" Hex Bolts (227), four 1/2" Washers (237) and two 1/2" Nylon Nuts (240). Attach a 45mm X 75mm Rect. Cap (214) to the bottom rear of the Leg Press Main Frame (202). Attach a 50 mm Sq. Caps (215) to each end of the Base Stabilizer (201).
- Slide a Bearing Housing (212) onto each end of the welded axle on the Rear Leg Press Support (208) and then bolt the Bearing Housings (212) to the Leg Press Main Frame (202) using four 1/2" X 1-3/4" Hex Bolts (228), eight 1/2" Washers (237) and two 1/2" Nuts (240).
- 4. Attach the Front Leg Press Support (206) to the Leg Press Main Frame (202) using one 5/8" X 6-1/2" Hex Bolt (226), two 5/8" Washers (236) and one 5/8" Nylon Nut (239).
- Attach the Foot Plate Connector (209) to the Rear Leg Press Support (208) and the Front Leg Press Support (206) using one 5/8" X 6-1/2" Hex Bolt (226), two 5/8" Washers (236) and one 5/8" Nylon Nut in each Leg Press Support.
- Attach the Foot Plate (210) to the Foot Plate Connector (209) using two 1/2" Washers (237) and two 1/2" Nylon Nuts (240). Attach two 45mm X 75mm Rect. Plugs (216) to the Foot Plate (210).
- Attach the Right and Left Leg Press Handles (203 & 204) to the Leg Press Main Frame (202), angle facing up, using two 3/8" X 3-1/8" Hex Bolts (230), four 3/8" Washers (238) and two 3/8" Nylon Nuts (241).
- Attach the Seat Pad for Leg Press (225) to the Leg Press Main Frame (202) using two 3/8" X 1" Hex Bolts (234), one 3/8" X 2-3/4" Hex Bolt (231) and three 3/8" Washers (238). Attach the Back Pad for Leg Press (224) to the Back Pad Adjuster (211) using two 3/8" Washers (238) and two 3/8" X 1" Hex Bolts (234). Screw the Locking Spring Knob (220) into the Leg Press Main Frame (202) and the slide the Back Pad Adjuster (211) into the Main Frame. Adjust to the desired position by pulling the Locking Spring Knob (220).

Tighten all bolts gradually, from ground - up.



STEP 3


bolt end

LEG PRESS CABLE (243)

────⊂⊖ metal ball end

- 1. Screw the threaded end (approximately half way) of the Leg Press Cable (243) into the Single Pulley Block (27) as shown in Fig. 1.
- 2. Route the cable up and over the right side pulley in the Top Frame (5) as shown in Fig. 2. Mount the pulley using one 3/8" X 2-3/4" Hex Bolt (89) and one 3/8" Nylon Nut (107).
- 3. Continue to route the cable down to the pulley on the Base Frame (1) as shown in Fig. 3. Mount the pulley using one 3/8" X 1-3/4" Bolt (91) and one 3/8" Nut (107).
- 4. Then route the cable up to the lower pulley in the Adjustable Pulley Block (25) as shown in figure 4. Attach the pulley to the second hole from bottom. The multiple holes are for cable adjustment. When cabling is complete, this pulley can be moved upward to take up slack, or downward to gain length.
- Continue to route the cable down to the pulley on the Base Frame (1) just behind the weight stack, as shown in Fig. 5. Mount the pulley using one 3/8" X 1-3/4" Bolt (91) and one 3/8" Nut (107).
- 6. Continue to route the cable underneath the weight stack and around the horizontally mounted pulley on the Leg Press Main Frame (202). Mount the pulley using one 3/8" X 1-3/4" Bolt (233) and one 3/8" Nut (241) as shown in Fig. 6.
- Continue to route the cable through the slot in Leg Press Main Frame (202), and under and around (exiting on the top) the lowest pulley on the Rear Leg Press Support (208) as shown in Fig. 7, Step 1. Mount the pulley using one 3/8" X 1-3/4" Bolt (233) and one 3/8" Nut (241).
- Then route the cable under and around (exiting on the top) the right side (as if sitting on seat) pulley mounted in Leg Press Main Frame (202) as shown in Fig 7. Mount two pulleys here using one 3/8" X 2-3/4" Hex Bolt (232) and one 3/8" Nylon Nuts (241).
- 9. Route the cable in the same manner under and around the uppermost pulley mounted on the Rear Leg Press Support (208) as shown in Fig. 7, Step 2. Mount the pulley using one 3/8" X 1-3/4" Bolt (233) and one 3/8" Nut (241).
- 10. Route the cable in the same manner under and around the left side (as if sitting on seat) pulley mounted in Leg Press Main Frame (202) as shown in Fig 7.
- 11. Hook the ball end of the cable into the receptor on the Rear Leg Press Support (208) as shown in Fig. 8.

Hint: When viewed from the side, the Leg Press Cable should be a series of "loops". There should not be any "X's".



Assembly is complete! Please take the following steps before using the gym:

- 1.Make certain all bolts are tightened securely.
- 2.Make certain all cables are seated into all pulley grooves. A cable rubbingagainst steel will peel the nylon coating, voiding warranty and resulting in a need for replacement.
- 3.Pre-stretch the cables. Pull on the cables with great force, helping remove any kinks and providing any initial cable stretch.
- 4.Be aware the cables can loosen and slightly stretch upon initial use.
- 5.For better performance, apply a household lubricant (such as silicone) to any adjustable areas.
- 6.Enjoy many years of a Fit Lifestyle.

Thank you for purchasing the BodyCraft LEG PRESS **II**. If You have any questions, please call your local BodyCraft dealer or call our customer service department at 800-990-5556