

IMPORTANT SAFEGUARDS**READ AND FOLLOW ALL SAFETY INSTRUCTIONS**

1. Review the diagrams thoroughly before beginning. If you feel you do not have electrical wiring experience, refer to a do-it-yourself wiring handbook or have your fixture installed by a qualified licensed electrician.
2. All electrical connections must be in accordance with local codes, ordinances, and the National Electric code. If you are unfamiliar with methods of installing electrical wiring, secure the services of a qualified licensed electrician.
3. Before starting the installation, disconnect the power by turning off the circuit breaker or by removing the appropriate fuse at the fuse box. Turning the power off using the light switch is not sufficient to prevent electrical shock.
4. Do not mount near gas or electric heaters.
5. The use of accessory equipment not recommended by the manufacturer may cause an unsafe condition.
6. Do not use this equipment for other than intended use.
7. Qualified personnel should perform all servicing onlu.

IMPORTANT SAFEGUARDS

1. Remoe the old device from the electrical box in a retrofit application.
2. Twist together bare copper ends of conductors as follows: RED (not) conductor from power source to RED wire on device. WHITE (neutral) conductor from power source to WHITE conductor on device. Screw on wire connectors and then secure wire connectors with UL listed electrical tape.
3. Mount device in the electrical box, with "TOP" up, using the screws provided.
4. Place PLATE and tighten cover screws.
5. Restore power at circuit breaker of fuse. Installation is completed.

CAUTION

Avoid contacting bulb with flammable materials. Do not cover light with drapes, blankets etc block ventilation, as overheating may occur. Use only a light emitting diodes for replacement.

