



e-Pro Power Qi 10K



**10K WIRELESS
CHARGER**

powered by
ec:sense

E-PRO POWER QI 10K WIRELESS CHARGER

**IMPORTANT: READ AND RETAIN THIS MANUAL
BEFORE FIRST USE!**

SPECIFICATION:

Battery: Lithium-ion Polymer

Capacity: 10,000mAh (29.6Wh)

Input ports: Type-C & Micro USB (DC5V=2A (max))

Output: USB (DC5V=2.0A (max)) + Type-C

Wireless Output: 5W

Size: 145.0*72.0*13.5mm

Material: Recycled ABS

Product overview:

1. Wireless charging indicator
2. Wireless charging area
3. Micro USB input port
4. Power Button
5. USB A output port
6. Type-C input/output port
7. Power indicator light



CHARGING THE E-PRO POWER Qi 10K:

Connect the Micro USB end of the provided cable to the Micro USB port on the e-Pro Power Qi 10K (take care) and connect the USB end to a USB port or mains adaptor (not included) to charge it. Charging is complete when all LEDs are illuminated.

Note: Charging via the mains is best

USING THE WIRELESS CHARGER:

Click the button to place the mobile phone to be charged on the wireless charging symbol surface of the mobile power supply, A red light indicates charging your phone

Wired Charging

1. Connect the supplied USB cable (or your own) to the USB port on the e-Pro Power Qi 10K
2. Connect your device to the other end of the cable (take care), charging will begin automatically

Wireless Charging

1. Press the power button on the end of the e-Pro Power Qi 10K
2. Place your Qi enabled device on the raised charging area, a red LED indicates charging

Note: Do not cover the powerbank or your device during charging, remove any cases. Do not place metal object on the charging area, keep out of reach of children. Ensure the coil on the e-Pro Power Qi 10K and your device are correctly aligned.

SAFETY INFORMATION:

Visit bitmore.co.uk for our T&Cs

1. Keep the e-Pro Power 10K away from fire and other sources of heat.
2. Please only use the supplied charging cable and your original certified cabled provided by your device manufacturer.

- 3.** Do not expose this product to water or liquids. If liquid enters the e-Pro Power 10K or encounters it, your device, or the charging cable, immediately unplug the product from any connected power sources or devices. Dispose of the e-Pro Power 10K at your local refuse centre. Liquid ingress will void the Bitmore guarantee.
- 4.** Do not exceed 5.0-5.5V power input
- 5.** Do not disassemble or modify the product
- 6.** Do not leave children below 16 years of age alone with the e-Pro Power 10K
- 7.** Avoid dropping this product (or any other heavy impact which might damage the internal circuit). This may cause it to swell and will void the warranty
- 8.** Avoid cleaning the e-Pro Power 10K using liquids or chemical substances (use a dry cloth only)
- 9.** The e-Pro Power 10K is not a toy
- 10.** Do not simultaneously re-charge and discharge
- 11.** When the e-Pro Power 10K is not being used for prolonged periods of time please charge it every 3 months to avoid damaging the battery
- 12.** Do not leave the e-Pro Power 10K charging over night or unattended
- 13.** Cease use immediately if the e-Pro Power 10K is wet, the casing is damaged or ports are damaged, it produces an abnormal smell, discolouration, shape or it overheats
- 14.** The e-Pro Power 10K is supplied partially charged so you can use it immediately.
- 15.** The e-Pro Power 10K will charge most mobile phones/devices up to 3 times, however this is dependent on the size of the battery in your mobile phone/devices. Some larger batteries may only be able to be charged 2 or 3 times
- 16.** Bitmore and its partners assume no responsibility for damage/faults because of improper use of the e-Pro Power 10K
- 17.** Take care when using the integrated cables, or connecting and disconnecting external cables to the ports on the e-Pro Power 10K, and when connecting them to your devices
- 18.** Bitmore and its partners assume no responsibility for damage to any devices connected to the e-Pro Power 10K, visit Bitmore.co.uk for more details
- 19.** Do not pack the e-Pro Power 10K into cargo luggage when flying, keep it in your hand luggage
- 20.** For optimal performance and to use the 5W fast charging capability, please use a QC compatible power adaptor and USB Type C that supports fast charging.
- 21.** DO NOT place any metals (including a device case/cover that has metal components) on the phone or device whilst the device is in use. You risk potential electrical shocks, static or other more dangerous incidents such as fire or death

- 22.** If you do not put your Qi enabled device in the correct charging position, your device and the device may become hot. This is due the receiving coil in your device and the charging coil in the device not being properly aligned. Placing metallic objects on the device or your device may also cause your device, device or those objects to get hot. When using the device with your Qi enabled device, ensure it is in the correct position as shown above, ensure that you remove any case on your device and that there are no metallic objects on your device or the device.
- 23.** The device has built in overcurrent protection. If the device is used improperly and the instructions in this guide are not followed, the device may shut down or reduce the power output and charging speed. Please check that your device is Qi wireless enabled and is functioning correctly and does not have any form of damage (software of hardware) as this may activate the overcurrent protection feature.
- 24.** The device must only be used and stored in an ambient environment with a temperature between 0-45 °C.
- 25.** DO NOT use or expose the device or your device to areas of high humidity, any liquids, gels or aerosols or heavy dust, keep it dry and clean.
- 26.** DO NOT take the device apart or attempt to modify, amend or repair it. This will damage the device, void the guarantee and may cause injury or death to you and those around you, or damage to property.
- 27.** When charging your device, it (your device) must be Qi charging enabled. Your device will not charge properly or may not experience fast charging if any of these situations are true; (a) Your device has more than 60% battery power. (b) iOS version below 11.1.2. (c) Device temperature is more than 35-45 ° C.
- Once your device is fully charged, remove it from the device. DO NOT leave it on the device.

24-MONTH LIMITED GUARANTEE:

You must register your device via bitmore.co.uk within 30 days for purchase for the guarantee to be valid.

Subject to applicable law, Bitmore (owned and operated by Nuwave Channel Partners Ltd, hereinafter "Bitmore"4), sell its products (hereinafter "Product(s)") with the intent that they are free of defects in manufacture and workmanship for 24-months from the date of original purchase, except as noted below. Bitmore warrants that its Products will be free of defects in material and workmanship under normal use and service. This guarantee extends only to consumers and does not extend to Retailers. Bitmore does not authorize anyone, including, but not limited to, retailers, the subsequent consumer purchaser of the product from a retailer or remote purchasers, to obligate Bitmore in any way beyond the terms set forth herein. This guarantee does not cover damage caused by misuse or abuse; accident; the attachment of any unauthorized accessory; alteration to the product; improper

installation; unauthorized repairs or modifications; improper use of electrical/power supply; loss of power; dropped Product; malfunction or damage of an operating part from failure to provide manufacturer's recommended maintenance; transportation damage; theft; neglect; vandalism; or environmental conditions; loss of use; or any other conditions whatsoever that are beyond the control of Bitmore. THE GUARANTEE PROVIDED HEREIN SHALL BE THE SOLE AND EXCLUSIVE GUARANTEE. THERE SHALL BE NO OTHER WARRANTIES EXPRESS OR IMPLIED INCLUDING ANY IMPLIED GUARANTEE OF MERCHANTABILITY OR FITNESS OR ANY OTHER OBLIGATION ON THE PART OF THE COMPANY WITH RESPECT TO PRODUCTS COVERED BY THIS GUARANTEE. BITMORE SHALL HAVE NO LIABILITY FOR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES. IN NO EVENT SHALL THIS GUARANTEE REQUIRE MORE THAN THE REPLACEMENT OF ANY PART OR PARTS WHICH ARE FOUND TO BE DEFECTIVE WITHIN THE EFFECTIVE PERIOD OF THE GUARANTEE. REFUNDS WILL BE GIVEN IF REPLACEMENT PARTS FOR DEFECTIVE MATERIALS ARE NOT AVAILABLE, BITMORE RESERVES THE RIGHT TO MAKE PRODUCT SUBSTITUTIONS IN LIEU OF REPAIR OR REPLACEMENT. This guarantee does not extend to the purchase of opened, used, repaired, repackaged and/or resealed products, including but not limited to sale of such products on Internet auction sites and/or sales of such Products by surplus or bulk resellers. Any and all warranties or guarantees shall immediately cease and terminate as to any Products or parts thereof which are repaired, replaced, altered, or modified, without the prior express and written consent of Bitmore.

This Agreement is made for the benefit of the parties and is not intended to benefit any third party or be enforceable by any third party. The rights of the parties to terminate, rescind, or agree any amendment, waiver, variation or settlement under or relating to this Agreement are not subject to the consent of any third party.

This guarantee provides you with specific legal rights. You may have additional rights which may vary from country to country. Because of individual regulations, some of the above limitations and exclusions may not apply to you.

NUWAVE CHANNEL PARTNERS LTD,
PARK HOUSE, 15-19 GREENHILL CRESCENT,
WATFORD, WD18 8PH, UK

NUWAVE CHANNEL PARTNERS BV,
KAPELLERLAAN 19,
6041 JB ROERMOND, NL

-
justask@bitmore.co.uk
FOR TECHNICAL SERVICE,
PLEASE CONTACT: +44 (0)20 3026 2608
-



bitmore.co.uk