


CityRabbit™

USER MANUAL



CR v2

SAFETY PRECAUTIONS


1. Do not attempt to ride up or down stairs, or jump over obstacles
2. Do not ride in a ponding that is higher than 2 cm (0.78 inches)
3. Do not ride with anyone else, including children
4. Do not keep your hand away from handlebar
5. Do not ride in heavy rain



Wear a helmet and knee pads in case of falls and injuries when you learn to ride the scooter



HOW TO RIDE

1. Step on the deck with both feet placed in front of the two rear wheels





2. Press the accelerator down to initiate speed

3. Press the brake lever to initiate braking




DISPLAY

Drive mode _____




CHARGE AND ADJUSTMENTS



— Charging

— Full/disconnected



Bag hook

Open lever to fold stem

Charge port.

NB: Do not leave unattended while charging.

BY: CITY MOBILITY CREW AS
MODEL NR.: CR-V2
RATED POWER: 350W
INPUT VOLTAGE: 48V
BATTERY: 9.0AH
MOTOR: 350W
MAX SPEED: 20 KM/H (15,5 MPH)
MAX LOAD: 100 KG

SERIAL NR.:

