

57.3 Design by Omer Arbel PRODUCT SPECIFICATION

PENDANTS:	three
MOUNTING:	deep white canopy 116mm (4.5") in diameter x 40mm (1.6") deep
LAMPING:	1.5w LED
CABLE LENGTH	3m (10') / 6m (20') / 15m (49')
STEM LENGTH	0.9m (3') or 1.8m (6') long stem
MATERIALS:	blown and dipped grey or white opaline glass, electrical components, black or white canopy
WEIGHT:	approximately 5.4kg (12lb) / 6.3kg (14lb)
POWER SUPPLIES:	integral

DESCRIPTION

The stem cable suspended horizontal system comes in a black or brass stem with a 116mm (4.5°) diameter white or black canopy rated for ceiling use.

57 is an exploration of a technique used for producing closed cell foam. The process involves trapping voids of air of different sizes and configurations within a glass matrix, yielding a shape loosely referencing a rain cloud. These pockets of air remain invisible when the piece is off, but come alive to reveal an interior universe when the piece is illuminated. By virtue of the fabrication process, each piece is completely unique.

NOTES

+ Purchase replacement lamps online at www.bocci.com/shop/bulbs

+ The brass used in our Stem Series is untreated and, as such, will develop a natural patina over time. To avoid any marking or tarnish on the brass during handling and installation, please use the gloves provided in your shipment.


US Patent # D796732 EU Design Patent # 002268581-0001 to 0006

Made in Vancouver, Canada

approx 5.4kg (12lb) Sales@bocci.com approx 6.3kg (14lb) WWW.bocci.com Berlin europe@bocci.com www.bocci.com

BOCCI

© 2020, Bocci Design and Manufacturing Inc. All rights reserved. Any inquiries should be directed to: info@bocci.com




1

Thread the pendant mounting plates onto the stem.

Very carefully uncoil the braided coaxial cable in a spool like manner. Insert your index fingers into opposite sides of the roll then rotate your fingers around each other to unroll the coaxial cable.

Use patience: allow the cable to uncoil completely to avoid kinks.


Note: Bocci recommends wearing thin gloves during installation to protect the stem finish and the glass surface.



Determine the overall drop.


Feed coaxial cable into canopy and set the length with set screw.

Note: this portion of the install will be done on the ground.



Leave a minimum 160mm (6-1/4") cable for next step.


Using a tool or your hands, pry a small hole in the braided cable to expose the two cables inside. Pull out the insulated cable and the aircraft cable.



STEM - CABLE SUSPENDED, HORIZONTAL

57.3 Design by Omer Arbel PRODUCT INSTALLATION INSTRUCTIONS






6

The client is responsible for ensuring fasteners are attached to a robust structural substrate.

Affix mounting plate to surface with fasteners provided.

Note: Gently pull the coax cable to make sure cable is secured before attaching the canopy to the ceiling.



8

on the ceiling.

screws.

Thread the stem onto the connector that is located at the end of the coax cable.

7

Carefully insert provided lamps into sockets. Check that each lamp is working properly as you go along by keeping power to the fixture on.

> Thread the swag hook on to the mounting plate, ensuring all the threads are engaged.

attaching swag hook with the provided


mounting plate

swag hook

വദ

(1)

Slide the ball end of the aircraft into the slot on the swag hook and secure with set screw.



Made in Vancouver, Canada


0001 to 0006


EU Design Patent # 002268581-


STEM - CABLE SUSPENDED, HORIZONTAL

57.3 Design by Omer Arbel PRODUCT INSTALLATION INSTRUCTIONS









1

Remove the pendant that is closest to the middle of the stem pole, exposing the pendant mounting plate.

Note: The levelling kit should only be attached once the system is installed to the desired height.

. .

2

Mark the location for the swag hook on the ceiling (directly above the pendant you just removed).

Ensure that the ceiling at the swag location is strong enough to hold 2kg (5lbs) before installing the swag hook mounting plate with the provided screws.

Thread the swag hook on to the mounting plate, ensuring all the threads are engaged.

Slide the ball end of the aircraft into the slot on the swag hook and secure with set screw.

Form a loop with the end of the aircraft cable around the front of the pendant mounting plate.

3

Secure the aircraft cable with the provided crimp (crimping tool not included). Trim the aircraft cable close to the crimp.

Note: Make sure the aircraft cable is straight and tight before securing it with a crimp.

4

Thread the pendant back onto the mounting plate. Clean fingerprints from fixture surfaces.

Note: Bocci reccomends wearing thin gloves during installation to protect the stem finish and the glass surface.

For additional assistance, please contact Bocci:

Vancouver sales@bocci.com www.bocci.com

Berlin

europe@bocci.com www.bocci.com

US Patent # D796732 EU Design Patent # 002268581-0001 to 0006

Made in Vancouver, Canada





