



INSTALLATION OF 60 AMP MANUAL RESET BREAKER



1. Determine a suitable mounting location for the Circuit Breaker in your boat. (We recommend installing the breaker as close as possible to the battery / batteries.)
2. Mount the Circuit Breaker using the two holes in the breaker base. (Mounting hardware not included.)
3. Connect the trolling motors positive (+) power cable to the terminal marked "AUX" on the Circuit Breaker.
4. Connect the Circuit Breaker terminal marked "BAT" to the positive (+) battery post.
(See diagrams below for 12, 24 and 36v use.)



INSTALLATION OF 60 AMP MANUAL RESET BREAKER



1. Determine a suitable mounting location for the Circuit Breaker in your boat. (We recommend installing the breaker as close as possible to the battery / batteries.)
2. Mount the Circuit Breaker using the two holes in the breaker base. (Mounting hardware not included.)
3. Connect the trolling motors positive (+) power cable to the terminal marked "AUX" on the Circuit Breaker.
4. Connect the Circuit Breaker terminal marked "BAT" to the positive (+) battery post.
(See diagrams below for 12, 24 and 36v use.)





NOTE: The 24 / 36 volt diagrams shown here show a series link being made at the batteries. Some installations will have the series link made at the trolling motor plug or plug receptacle.

P/N 237-4919 Rev. A 5-04



NOTE: The 24 / 36 volt diagrams shown here show a series link being made at the batteries. Some installations will have the series link made at the trolling motor plug or plug receptacle.

P/N 237-4919 Rev. A 5-04