



Quick start manual

- |                      |                    |
|----------------------|--------------------|
| 1. Start using       | 2. Basic functions |
| 3. Reminder function | 4. Waterproof      |


# 1 Start using

---

This device integrates outdoor GPS, multi-sports mode, sleep monitoring, heart rate monitoring, call reminder, information push and so on. It is suitable for a variety of life scenarios.

## 1.1. Charge, turn on/off device

Make sure that the metal contacts on the charging base are in place with the metal contacts on the back of the unit. A charging prompt will appear on the screen when the power is connected. When not charging, pull out the charging cable to prevent the contact from touching the metal object and causing fire.



Charging diagram

## Notes:

- Please charging with the matched charging cable, and keep charging port clean and dry before charging
- Make sure touch properly, please charge longer and check further if no charge icon on the display.

**Turn on the device:** Long press the side button.

**Turn off the device:** Long press the side button.

## 1.2. Download and install APP

Scan QR code to download directly, or input "FunDo" on APP store, Google Play to download and install.



FunDo

## 1.3. Connect device to mobile phone

Start the FunDo APP(hereafter called APP), set account, profile etc, do step by step as per the APP guide.

## 1.4. Basic operation

- 1) Touch buttons or physical buttons for quick and easy operation.
- 2) Side button
  - Light up screen
  - Back
- 3) Touch button
  - The main interface of the dial slides up-down to switch between different function pages.
  - The main interface of the dial slides to the left to open the first menu.
  - The main interface of the dial slides to the right to view the message, and in the other interface slides to the right to back.
  - Long press the main interface of the dial to switch the different dial.
  - The motion function can be operated by clicking the motion icon of the first menu, and clicking the corresponding icon can end the motion function.

# 2 Basic functions

---

- 2.1. The device supports outdoor sports GPS positioning and real-time recording of motion track.
- 2.2. The device has included some kinds of sensors, wearing on the wrist to detect activity, sleep, heart rate, and other fitness status and record data.
- 2.3. The device could automatically detect and record the daily activity data while wearing, push the touch area to the sports page, could check steps, distance, burnt calories.
- 2.4. The device supports sleep monitoring at night automatically, tap the touch button and switch



to sleep page to check the sleeping data. At present, it doesn't support to monitor afternoon nap or the abnormal sleep detection(such as work at night, sleep in the daylight)

- 2.5. The device support Heart rate detection, push touch area to heart rate page respectively to start testing directly.
- 2.6. The device supports multi-sport mode, touch the button to the motion page to select the corresponding mode to start the exercise, and also supports the target setting.

### Notes:

- The device is not medical device, the data is just for reference.
- The normal sleep detection technology is based on acceleration instead of body physical feature index, data is just reflect general status for reference. Sleep-in and wake-up status is recognized related to some times and some data, quiet lying is probably to be judged as sleeping.
- Generally, the device time does not need to be set. After the device is successfully bound to the APP, the time of the mobile phone is automatically synchronized to the device. If you need to adjust the time, please find the time setting modification in the phone settings, then reconnect the APP and pull down the home page to synchronize.

## 3 Reminder function

---

- 3.1. **Call reminder:** When the mobile phone calls, the device will remind you that you can.
- 3.2. **Message Reminder:** When the mobile phone status bar receives a new message prompt, the device will remind you to view the reminder content on the device.

## Notes:

- The reminder mode has three choices: bright screen, vibration, bright screen + vibration;
- Call/message reminder is based on well connection between the device and mobile phone
- Need to set notification function available on your mobile phone, and turn on the message reminder function on APP.

# 4 Waterproof

---

- 4.1. The device support waterproof IP68, factory has tested and show the waterproof feature under the special situation.
- 4.2. The waterproof level is lower along with time.
- 4.3. Could use in occasions: wash hand, rainy day, play water in the shallow water area, stop using it while taking hot shower, diving, surfing etc.

## **Note: Below occasions might affect device's waterproof, please be ware:**

- Device fall down, get hit, knock other things.
  - Device has soap water, shower gel,detergent,perfume,lotion,oil etc.
  - Taking hot shower, spa, this kind of high temperature/moisture occasion.
- 4.4. It is beyond warranty scope if damage causes by liquid inside.