



Application Instructions

1. Locate MKO label at top of brace.
2. From top fold upper half of brace inside out.
3. Grab support near silicone inserts and pull up arm.
4. Make sure inserts are slightly below elbow joint.
5. Unroll upper portion above elbow.
6. Adjust where needed making sure the brace has a comfortable compression. The brace should not cut off circulation nor should it slide down the arm. Compression strap is provided if further support is required.

To prevent moisture build up, store brace in an open dry area between uses.