Plank Bench

1 Fasten the coupling arms to the bench sides.

2 Attach the bench sides to the support rail and secure by tightening the coupling catches (See FIG.1).

3 Secure the dowels into the appropriate holes on the bench sides.

4 Secure the four threaded rods into the underside of the bench top.

 ${\bf 5}\,$ Align the bench top with the base, securing the dowels and threaded rods into their appropriate holes.

6 With the bench turned upside-down on a clean, soft surface such as a rug, fit the crescent spacers over the protruding threaded rods, then tighten the washers and hex nuts to the rods (See FIG.2a & FIG.2b).

7 Secure the bolts and remaining washers through the support rail and into the underside of the bench top, using the provided allen key (See FIG.3).

FIG. 1

100

' (Q\$9)

COUPLING CATCH

8 Snap the hole covers over the circular openings.





