


# Blocking the Pwani Shawl



- 1) Straighten the top edge. Use a short blocking wire if you like, although smoothing it with your hands will work well too.
- 2) Find the centre point of the bottom edge. Align it with the centre point of the top edge.
- 3) Smooth the bottom curve, using blocking wires if you have them. Bend the blocking wires out and pin them to secure the curve.
- 4) Stretch the top points and curve them inwards. Try to get them inline with each other to create symmetry.



A tutorial by *Clare Devine*