

FRONT BASKET ASSEMBLY INSTRUCTIONS

REID
reidcycles.com.au

MELBOURNE | SYDNEY | BRISBANE | PERTH | ADELAIDE

PARTS INCLUDED

- » Wicker basket and basket frame
- » Axle stays
- » Stem bracket (non-threaded plate)

TOOLS REQUIRED

- » 4mm allen key
- » 6mm allen key
- » 8mm spanner

BASKET & FRAME

AXLE STAYS

STEM BRACKET



ASSEMBLY INSTRUCTIONS

- 1** Use the nuts/bolts provided to attach the steel basket frame to the Stem Bracket.
Insert the bolts into the support plate in the basket and towards the handlebars/stem. Tighten.
- 2** Loosen the nut on top of the stem that holds the handlebars and stem in place. Lift the handlebars upward to remove.
Remove the hexagonal lock nut on top of the head tube, remove washer and put the Stem Bracket in place.
Reattach the hexagonal lock nut and the handlebars/stem making sure the handlebars are aligned at right angles with the front tyre. Tighten the nut.
- 3** Remove the axle nuts and place the bottom of the Axle Stays over the axle.
Reattach the axle nuts.
Place the hasp bracket under the top of the Axle Stay and use the screws provided to attach the plate in the basket to the Axle Stays.
- 4** Place the cane basket inside the steel mesh frame and...

you're ready to go!

