Sizing Guide


Your child must be standing when you measure his/her feet with toes resting flat. Place "heel" edge of chart against a wall. Tape chart to floor for added stability. Place heel at the bottom edge of the chart. Measure to the longest toe.

Measure both the right and left foot for accuracy.

When ordering, use the largest of the two dimensions.

IMPORTANT: 0.5 cm should be added to the measured length of your child's feet in order to provide more comfort.

Example: If you measure 14cm, corect size would be 23 (14.5cm)



For baby sizing, please use section below.

Baby Sizing

18-24 mos. / EU 21

12-18 mos. / EU 20

6-12 mos. / EU 19

0-6 mos. / EU 17-18

 $\begin{array}{rrrr}
-25 & -38 & -24 & -37 & -24 & -37 & -24 & -37 & -24 & -37 & -24 & -27 & -26 & -27 & -$

-16 —

— 11 — 17 — 17 — 10 — 16 — cm SIZE





Before you print the sizing chart, make sure you choose the option »Actual size« or 100%.

Match the size of a credit card to the corresponding graphics at the bottom of the chart or measure with a ruler cm scale on the chart. If none of those options match with your printed chart, you will need to reprint with the correct settings.

Match credit card here to ensure this page was printed to scale!

If you have any questions, please email support@ciciban.ca or call 1.888.547.1207

Place heel here!



www.ciciban.com