


SUSPENSION SEATPOST QUICK START

How to correctly install your suspension seatpost

MAX Weight Capacity: 220lbs


STEP 1

Use a 14mm wrench to loosen the nuts on the bottom of the saddle rails and separate the saddle from the seat post.



STEP 2

Insert your new suspension seatpost into the frame and re-engage the seatpost collar. At this time you can slightly adjust the tilt of your seat and the front to back position.



STEP 3

Make sure to evenly tighten both sides until wrench leaves an impression on your palm.

