

### 80 WATT CREE 1156 LED TURN SIGNAL BULBS INSTALL GUIDE



#### TOOLS/ITEMS YOU WILL NEED:

- (2) 1156 LED TURN SIGNALS (RED OR AMBER)
- (2) 50W 60HM RESISTORS
- (2) WIRE TAPS (INCLUDED WITH RESISTORS)
- SHARP BLADE OR KNIFE
- SOCKET WRENCH W/ 10MM SOCKET
- ELECTRICAL TAPE

#### OPTIONAL ITEMS:

- SOLDERING IRON
- SOLDER
- RUBBER MALLET



#### STEP 1:

REMOVE PLASTIC PANEL COVERING TAIL LIGHT ACCESS  
(DRIVER'S SIDE SHOWN FIRST)




## STEP 2:

REMOVE (3) 10MM BOLTS HOLDING IN THE TAIL LIGHT




## STEP 3:

REMOVE TAIL LIGHT. TAP THREADS WITH RUBBER Mallet TO HELP EASE THE LIGHT OUT.  
BE AWARE OF THE WHITE CLIP ON THE SIDE;  
THE LIGHT SLIDES RIGHT OFF OF IT



## STEP 4:

LOCATE THE BLUE WIRE WITH ORANGE STRIPE  
LOCATE THE BLACK GROUND WIRE (CORNER PIN)



### STEP 5:


REMOVE THE STOCK TURN SIGNAL BULB  
(ORANGE HOLDER)

REMOVING THE SMALL PLASTIC CLIP MAKES IT EASIER



### STEP 6:

INSTALL CREE LED TURN SIGNAL  
AND REPLACE ORANGE HOLDER



### STEP 7:

INSTALL 50W RESISTOR BETWEEN  
BLUE WITH ORANGE STRIPE (+)  
AND BLACK (-) WIRES  
USING WIRE TAPS  
(OR CUT AND SOLDER IF YOU PREFER)



**STEP 8:**  
REMOVE PLASTIC PANEL COVERING TAIL LIGHT ACCESS  
(PASSENGER SIDE SHOWN)



**STEP 9:**  
REMOVE (3) 10MM BOLTS HOLDING IN TAIL LIGHT




**STEP 10:**  
REMOVE ORANGE BULB HOLDER TO REPLACE BULB



**STEP 11:**  
INSTALL CREE LED TURN SIGNAL  
AND REPLACE ORANGE HOLDER



**STEP 12:**  
LOCATE THE RED WIRE WITH ORANGE STRIPE  
LOCATE THE BLACK WIRE (CORNER PIN)



**STEP 13:**  
INSTALL 50W RESISTOR BETWEEN  
RED WITH ORANGE STRIPE (+)  
AND BLACK WIRE (-) WIRES  
USING WIRE TAPS  
(OR CUT AND SOLDER IF YOU PREFER)



## STEP 14:

REINSTALL TAIL LIGHTS AND VERIFY FUNCTIONALITY

(RED LED BULBS SHOWN, IN DARK AND LIGHT SETTINGS)

