



# TILE - LINED SHOWER INSTALLATION




**01** Fix cups to the frame so that they will finish flush with the wall lining. Plumb out the fittings.


\*use the supplied packers if needed to achieve the correct set back requirement for the water control valve.




**02** Remove the manufacturer's recommended size access hole for the mixer from the large flange. Remove a 30mm hole from the small flange.




**03** Remove a 180mm hole and a 115mm hole from the wall lining to match the cups. The cups must finish flush with the face of the wall lining. Fix the wall lining in place.




**04** Apply a bead of sealant to the channel on the flanges and firmly push the flanges onto the cups.




05 Apply a waterproof membrane to the wall lining.



06 Apply a horizontal bed of tile adhesive to the waterproof membrane.



07 Apply sealant around the access holes.



08 Cut tiles to match access holes. Fix the tiles to the adhesive and the sealant.

[sales@wetwallcaddy.nz](mailto:sales@wetwallcaddy.nz)  
[www.wetwallcaddy.nz](http://www.wetwallcaddy.nz)

Copyright © 2009 Aquatite Enterprises Limited. All rights reserved. This document may not be reproduced or republished in whole or part in any form without the prior written consent of Aquatite Enterprises Limited. While every precaution has been taken in the preparation of this literature, Aquatite Enterprises Limited assumes no liability for errors or omissions, or from any damages resulting from the use of this information. The contents and any product specifications within this document are subject to revision due to ongoing product improvements and may change without notice. The Aquatite, Wetwall Caddy, and Cavity Cup names and logotypes are trademarks of Aquatite Enterprises Limited.

**PROTECT YOURSELF  
AND YOUR CLIENTS  
WETWALL CADDY™**