



Installation and Use Instructions for GRIPPS® Dropped Tool Prevention Equipment.

GRIPPS® Bolt-Vault
Model: H02105



H02105
Bolt-Vault
Max Load (D-Ring): 2.5kg/5.5lbs
Max Load (Pouch): 2.5kg/5.5lbs

For product support contact us at:

support@gripps.com.au | +61 3 8383 9458

WWW.GRIPPS.COM.AU | @GRIPPSGLOBAL | #CONQUERGRAVITY

GRIPPS® Bolt Vault

SAFETY INFORMATION

⚠️ WARNING Before using the GRIPPS® Bolt-Vault, read all provided safety information pertaining to the use of your Dropped Tool Prevention (DTP) device. **FAILURE TO DO SO COULD RESULT IN INJURY OR DEATH.**

The user of a DTP device bears the responsibility of reading all safety information contained herein. Keep this manual for future reference.

Intended Use:

When used properly, the GRIPPS® Bolt-Vault can prevent workplace hazards resulting from dropped tools. These may include personal injury and material damage.

GRIPPS® does not approve use of this device for any activities not described in the User Instructions. This device is not intended to be used in any recreational activity, as a personal fall-arrest device or in any other manner not described herein.

⚠️ WARNING Misuse of this device could result in serious injury or death.

Adhere to all manufacturer recommendations regarding the operation and maintenance of this device. For additional information, contact GRIPPS® customer support.

Read and adhere to the following in order to ensure correct operational functionality:

- Your DTP should never be used as a personal fall-arrest device or restraint system.
- Do not use this device with tools that exceed the specified maximum load/weight.
- A DTP device used in applications that exceed the limits of operation specified by the manufacturer should be considered unsafe and should be replaced.
- Do not tether a tool over 2.5kg/5.5lbs directly to your clothing or person.
- Inspect your DTP device before each use.
- Ensure the DTP device is securely connected to a load rated tool connector or anchor point before use.
- Inspect any tool connector point before it is connected to the DTP device.
- Modification of the DTP device voids all warranties and violates manufacturer recommendations.
- Do not use a tool that cannot be connected to your DTP in the manner specified by GRIPPS®.
- It is unsafe to extend the length of the DTP product by any means.
- Do not use this product if it will create an unsafe working environment.
- Use extra precaution around moving machinery, moving parts, electrical hazards, extreme temperatures, chemical hazards, or combustion hazards.
- Avoid contact between any connected tethers and rough or sharp edges.
- Regularly inspect the Velcro on the Bolt-Vault to ensure it is free from any dust, grime or debris.
- All connected tools and equipment, including connection points, must be compatible for use with this DTP device.

- Always wear appropriate personal protective equipment.
- If a tether has arrested a dropped tool or object, it should be taken out of service and replaced.
- All procedures shown in this instruction are for GRIPPS® Bolt-Vault products only.

GENERAL USE AND CARE

The GRIPPS® Bolt-Vault allows for the safe installation/manipulation of small objects, such as fittings, at height. It features nylon-weave panels that allow tools to be inserted whilst maintaining a controlled environment that protects against drops.

Recommended Use of the GRIPPS® Bolt-Vault:

1. Only connect additional tethers to the load rated D-Rings.
2. Ensure the Bolt-Vault has a snug fit around your wrist. If you cannot achieve a snug fit then do not use the Bolt-Vault.
3. Only use Bolt-Vault on bolts where there is a minimum 3.0cm/1.0" of exposed thread to insert through nylon weave.
4. Avoid unnecessary tugging or sharp movements when tools are inserted into the nylon-weave panels on the Bolt-Vault. This will increase its lifespan.

Before Use:

Thoroughly inspect your GRIPPS® DTP device before each use. Do not use any component that presents deformities or deterioration.

Bolt-Vault Usage Instructions:

To wear Bolt-Vault

1. Place hand inside Bolt-Vault, firmly strapping around the wrist by feeding the Velcro strap through the buckle and pulling tight.



To operate the Bolt Vault

1. Attach or disconnect fasteners by pushing the bolt through any of the nylon weave panels.



2. Tools such as a spanner can be inserted into the secondary nylon weave panel to manipulate the contents. The tool can be tethered to the load rated D-Rings on the Bolt-Vault. Do NOT put a tool into the same nylon weave panel as the bolt.



After Use Care:

Clean and inspect the Bolt-Vault and any connected tethers. For tougher stains, use warm water and a mild soap or detergent. Do not use again until dry.

Store in a clean and dry environment. Proper care will help to ensure that it will operate effectively and extend its service.



instagram.com/grippsglobal
facebook.com/grippsglobal
twitter.com/grippsglobal

Contact Support On
support@gripps.com.au
+61 3 8383 9458
#ConquerGravity