



Scary Good Pumpkin Ale



⚠ If your kit has **liquid yeast**, put it in the refrigerator as soon as possible.

Pumpkin ale, a fall classic. This brew will delight you with caramel and pumpkin flavors, topped off with a blend of pumpkin pie spices that's just right. The Scary Good Pumpkin Ale will make you wish that Halloween and Thanksgiving came along more than just one time per year! If you really want the taste of pumpkin pie a la mode, try throwing a vanilla bean or two in with the pumpkin pie spices.

Approximate calculations: OG: 1.060 FG: 1.014 ABV: 5.5% IBU: 18 SRM: 20

Kit Ingredients


- Specialty Steeping Grains:
 - 1 lb Caramel 20L malt
 - ½ lb Goldpils Vienna malt
 - 2 oz Chocolate malt
- 6 lb amber malt extract
- 1 lb brown sugar
- 1 oz Brewers Gold hops (3/4 oz at 30 min, 1/4oz at 5 min)
- 2 cans pumpkin puree
- 1 tsp pumpkin pie spices
- 1 cup corn sugar (for bottling)
- Muslin sack to steep grains
- BRY-97, Wyeast 1450, or WLP008

⚠ Please make sure that your kit contains these items. Please call us at 608-257-0099 before brewing if any item is missing. Thanks!

Directions

Sanitize everything well! Remember to stir periodically throughout the boil!

0. An optional step you may take would be to roast the pumpkin puree in your oven before brewing. Preheat the oven to 350F and bake for 30 minutes, stirring halfway through. This will help caramelize the sugars in the pumpkin.
1. If you are using liquid yeast, about three to six hours before you are going to brew, remove the liquid yeast from the refrigerator. If it is a Wyeast pack, break the nutrient pack inside the yeast package according to the directions on the package. Leave the yeast out at room temperature until it is time to pitch your yeast into your beer.
2. Fill your kettle with 8 quarts of cold water, pour the crushed **steeping grain** into the grain sack, tie the sack closed, and place it into your kettle (**Note:** If your brew system allows you to boil more than 8 quarts, feel free to boil more liquid. This will allow you to get a bit better utilization from your hops and reduce caramelization). Turn on heat and bring mixture to 155F and then turn off heat. Steep the grains for 20 minutes. Do **not boil** grains.
3. While your grains are steeping, heat 4 quarts of water to 170F in a separate pot. After the 20 minute steep, remove the grains from the mixture and rinse (sparge) them with the 4 quarts of hot water, collecting the runnings in your boil kettle. Then turn on the heat and bring the mixture to a boil. You will be boiling the mixture, called wort, for a total of 30 minutes. However, keep reading, because you'll be adding hops during that time.
4. When you achieve a boil, turn off heat and empty **amber extract** and **brown sugar** into hot water. (Extract may pour more easily if you open the container and place it in a saucepan of hot,



- not boiling, water for ten minutes prior to pouring. Do not apply direct heat to jar). Stir extract into wort well.
5. Turn heat back on and bring wort to a boil. Upon initial boil, wort may foam up (called a “hot break”). If this happens, reduce the heat until the foam recedes, then turn up the heat, bring back to a boil, and maintain a rolling boil. Start your 30 minute boil timer now. Add **3/4 oz of Brewers Gold** hop pellets and boil the wort for 15 minutes. This hop addition will impart most of the bitterness to your beer.
 6. After 15 minutes, add **1 can of pumpkin puree** and stir in well, continue to boil for 10 more minutes.
 7. After these 10 minutes (25 minutes total), it’s time for another hop addition. Add **1/4 oz Brewers Gold** hop pellets and the **brown sugar**, make sure to stir well, continue to boil for 5 more minutes.
 8. After these 5 minutes (30 minutes total), you are done boiling your beer, so it’s time to turn off the heat. Add the remaining **1 can of pumpkin puree**.
 9. Sanitize fermentor, stopper, and air lock with sanitizing material according to its directions.
 10. Fill the sanitized fermentor with 2.5 gallons of cold water (use less if you boiled more water than the recipe calls for). Cool your hot wort down to around 110-120F by placing your pot carefully into a sink of ice water for 15-30 minutes or by using a wort chiller. Carefully pour the hot wort into the cold water in the fermentor. It’s ok if some or all of the puree makes it into the fermentor. If necessary, top up to 5.25 gallons with cold water.
 11. Take a temperature reading of the wort. If the wort mixture in the fermentor is below 80°F (not warm to the touch), give the wort a good shake or a good stir with a sanitized metal or plastic spoon. Here you are trying to aerate the wort, which will help your yeast get going. This is also a good time to take a hydrometer reading. The number from this reading is your starting gravity. Add your beer **yeast**. Instructions are on the yeast package.
 12. Seal your fermentor. Attach the fermentation lock half filled with water. Ferment at 60°-72°F for around 14 days. Note that it can take up to 24 hours for active fermentation to be visible. If you don’t see any activity in the air lock or foam on the surface of beer after 24 hours, call us at 608-257-0099. If doing a double stage fermentation, siphon the beer into the glass carboy after 5-7 days in the primary fermentor (the beer may be transferred to the glass carboy as soon as the foam has fallen far enough so the carboy will not overflow).
 13. However you ferment, add your **spice packet** to your beer after 7 days of fermentation (if doing two-stage fermentation, add these hops when you siphon your beer into the secondary fermentor).
 14. After 14 days, if your beer has ceased fermentation, you can go ahead and bottle or keg your beer. Whether you bottle or keg, sanitize everything that will contact the beer during packaging, including bottles, caps, kegs, siphon tubing, bottle filler, etc. Also, now is a good time to take a hydrometer reading. This is your beer’s final gravity.
 - a. **Bottling, Single-Stage Fermentor:** Siphon beer into sanitized bottles. Pour just under 1 tsp. corn sugar in each bottle. Cap and turn bottles upside down several times to mix in sugar.
 - b. **Bottling, 2-Stage Fermentor:** Rack the beer carefully off the sediment into a sterilized fermentor or bottling bucket from the carboy. Bring ¾ pint of water to a boil. Turn off heat. Dissolve 1 cup of corn sugar in this hot water and stir gently into the beer. Bottle and cap.
 - c. **Kegging:** Siphon the beer into your sanitized keg, purge the oxygen from the head-space, hook up to your CO2, wait, and enjoy!
 15. Store upright at room temperature (~70F) for 14 days to carbonate. Beer may then be stored at cooler temperatures to age. Beer may be consumed at any time, though it will continue to improve for several weeks.