



# Piney the Antler

## Imperial IPA All-Grain Kit

---

⚠ If your kit has **liquid yeast**, put it in the refrigerator as soon as possible.

This kit's namesake (Pliny the Elder, from Russian River Brewing Company) is the most famous IPA in the country, and rightly so. Clocking in at 85+ IBUs and bolstered by a malt profile designed to let the hops shine, we think Piney the Antler does its inspiration justice.

**Calculated Approximate: O.G.: 1.078 F.G.: 1.017 ABV: 8% IBU: 85 SRM: 8**

**Please Note: This recipe and these instructions assume a 5 gallon batch size with 70% efficiency for a standard homebrewing setup. You may want to tweak the numbers to fit your brewhouse.**

The gravity, IBU, and SRM stats are approximations, so don't worry if you are a few points high or low.

### Kit Ingredients

- Specialty Steeping Grains:
  - 8 oz Cara 45L malt
  - 8 oz Carapils malt
  - 12 lb US Pale Ale malt
- 1 oz Warrior hop pellets
- 2 oz. Columbus hop pellets
- 2 oz. Centennial hop pellets
- 3 oz. Simcoe hop pellets
- 1 oz. Brewer's Gold hops
- 1 lb corn sugar
- 1 cup corn sugar (for bottling)
- US-05, Wyeast 1056, WLP090, OYL-052, or GY054 yeast.
- Recommended: CBC-1 bottling yeast

⚠ Please make sure that your kit contains these items and call us at 608-257-0099 before brewing if any item is missing. Thanks!

### Directions

**Sanitize everything well! Remember to stir periodically throughout the boil!**

0. If you are using liquid yeast, about three to six hours before you are going to brew, remove the liquid yeast from the refrigerator. If it is a Wyeast pack, break the nutrient pack inside the yeast package according to the directions on the package. Leave the yeast out at room temperature until it is time to pitch your yeast into your beer.

Because this is a high gravity ale, we HIGHLY recommend using one of the following methods to help your yeast ferment your yummy beer:

- a. Make a starter. About 2 days before you are going to brew, mix 3.5 oz of dry malt extract in 1 liter of water, boil for 15 minutes, cool down to below 80F, add your **yeast**, and let ferment for 24 hours. If you are not using a stir plate, you may want to swirl your starter a few times a day. After 24 hours, put the starter in the fridge and leave it in there until about 3 hours before you brew. When it is time to add your yeast at the end of the brew day, decant the liquid and add the yeast sludge at the bottom of the starter container.
  - b. Use multiple yeast packs.
1. Fill your kettle with 4.5 gallons of water and heat it to 161F. Pour crushed **grain** into your mash tun and add the water. Check the temperature, make sure it is 150F. If it is too low, add hot water to bring up the temperature. Mash the grains for 60 minutes.

2. While your grains are mashing, heat 4.5 gallons of water to 170F in a separate pot. After the mash, vorlauf (drain 1-2 liters, or until wort is running clear and return this liquid to the mash tun) and drain the liquid from the grain. Then, sparge (rinse) the grains with the 4.5 gallons of hot water, collecting the runnings in your boil kettle. Then turn on the heat and bring the mixture to a boil. While it is coming to a boil, stir in the **1 lb Corn Sugar**. You will be boiling the mixture, called wort, for a total of 60 minutes. However, keep reading, because you'll be adding hops during that time.
3. Upon initial boil the wort may foam up (called a "hot break"). If this happens, reduce the heat until the foam recedes, then turn up the heat, bring back to a boil, and maintain a rolling boil. Start your 60 minute timer at this point in the brewing process. Add **1 oz of Warrior** and **1 oz Brewer's Gold** hop pellets and boil the wort for 50 minutes. This hop addition will impart most of the bitterness to your beer.
4. After 50 minutes, turn off the heat and add **1 oz Simcoe** hop pellets to the kettle and boil for 10 more minutes.
5. After these 10 minutes (60 minutes total boil time), you are done boiling your beer, so it's time to turn off the heat. Once you have turned off the heat, add **1 oz Centennial**, **1 oz Columbus**, and **1 oz Simcoe** hop pellets.
6. Sanitize fermentor, stopper, and air lock with sanitizing material according to its directions.
7. Fill the sanitized fermentor with 2.5 gallons of cold water (use less if you boiled more water than the recipe calls for). Cool your hot wort down to around 110-120F by placing your pot carefully into a sink of ice water for 15-30 minutes or by using a wort chiller. Carefully pour the hot wort into the cold water in the fermentor. If necessary, top up to 5 gallons with cold water.
8. Take a temperature reading of the wort. If the wort mixture in the fermentor is below 80°F (not warm to the touch), give the wort a good shake or a good stir with a sanitized metal or plastic spoon. Here you are trying to aerate the wort, which will help your yeast get going. This is also a good time to take a hydrometer reading. The number from this reading is your starting gravity. Add your beer **yeast**. Instructions are on the yeast package.
9. Seal your fermentor. Attach the fermentation lock half filled with water. Ferment at 60°-72°F for around 17-21 days. Note that it can take up to 24 hours for active fermentation to be visible. If you don't see any activity in the air lock or foam on the surface of beer after 24 hours, call us at 608-257-0099. If doing a double stage fermentation, siphon the beer into the glass carboy after 10-14 days in the primary fermentor (the beer may be transferred to the glass carboy as soon as the foam has fallen far enough so the carboy will not overflow).
10. **Dry Hop Addition:** However you ferment, add **1 oz Simcoe**, **1 oz Centennial**, and **1 oz Columbus hop pellets** to your beer after 10-14 days of fermentation (if doing two-stage fermentation, add these hops when you siphon your beer into the secondary fermentor). Let beer sit on the hop pellets for 4-10 days.
11. After around 14-21 days, if your beer has ceased fermentation, you can go ahead and bottle or keg your beer. Whether you bottle or keg, sanitize everything that will contact the beer during packaging, including bottles, caps, kegs, siphon tubing, bottle filler, etc. Also, now is a good time to take a hydrometer reading. This would be your beer's final gravity.
  - a. **Bottling, Single-Stage Fermentor:** Siphon beer into sanitized bottles. Pour just under 1 tsp. corn sugar in each bottle. Cap and turn bottles upside down several times to mix in sugar.
  - b. **Bottling, 2-Stage Fermentor:** Rack the beer carefully off the sediment into a sterilized fermentor or bottling bucket from the carboy. Bring  $\frac{3}{4}$  pint of water to a boil. Turn off heat. Dissolve 1 cup of corn sugar in this hot water and stir gently into the beer. Bottle and cap.
  - c. **Kegging:** Siphon the beer into your sanitized keg, purge the oxygen from the head-space, hook up to your CO2, wait, and enjoy!
12. Store upright at room temperature (~70F) for 14 days to carbonate. Beer may then be stored at cooler temperatures to age. Beer may be consumed at any time, though it will continue to improve for several weeks to months.