


Hunter
SINCE 1886

Air Purifier & Humidifier



English

**Models:
HPH625
(All Colors)**

READ AND SAVE THESE INSTRUCTIONS

Form #HPH625

08102023

© 2023 Produced exclusively for Mindful LLC under license by Hunter Fan Company

All rights reserved

Table of Contents

Safety Instructions	1-3
Initial Setup	4
Operation	5
Control Panel	6
Display Screen	7
Remote Control	8-9
Maintenance	10-12
Troubleshooting	13
Customer Support	14
Limited Warranty	15-17

Safety Instructions

Your safety and the safety of others are very important.

We have provided many important safety messages in this manual and on your appliance. Always read and obey all safety messages.



This is the safety alert symbol. This symbol alerts you to potential hazards that can kill or hurt you and others.

All safety messages will follow the safety alert symbol and either the word "DANGER" or "WARNING." These words mean:



DANGER

You can be killed or seriously injured if you don't immediately follow instructions



WARNING

All safety messages will tell you what the potential hazard is, tell you how to reduce the chance of injury, and tell you what can happen if the instructions are not followed.

IMPORTANT SAFETY INSTRUCTIONS

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

Do not operate appliance with a damaged cord or plug. Discard product or return to an authorized service facility for examination or repair.

Unplug appliance before servicing.

Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar covering. Do not route cord under furniture, or appliances. Arrange cord away from traffic area and where it will be tripped over.

READ AND SAVE THESE INSTRUCTIONS

WARNING: To reduce the risk of fire or electrical shock, DO NOT use the appliance with any Solid-State Speed Control Device.

WARNING: To reduce the risk of fire or electrical shock and injury to persons, DO NOT use in a window.

Safety Instructions

Thank you for choosing the Hunter® Air Purifier & Humidifier! Please read and save these instructions to receive the maximum benefit and performance from your unit.

READ AND SAVE THESE INSTRUCTIONS!
Important Safety Instructions:
Read all instructions before using this humidifier

- This product may not work properly on an uneven surface. ALWAYS place this product on a firm, level, and water resistant surface.
- ALWAYS place the product at least six (6) inches away from walls, heat sources, and electrical appliances such as stoves, radiators, or heaters.
- ALWAYS place the product in an area that is out of the reach of children.
- Before using the product, extend the cord and inspect for any signs of damage. DO NOT use the product if the cord has been damaged.
- Do not use the product outdoors or in locations subject to rain, water, heat, fire or sun.
- Never wrap a power cord around product or other object. Doing so can stress the cord in ways that can cause the cord to fray, crack, or crimp. This can present a safety hazard.
- Protect power cord from liquids. Do not leave power cord near sinks, tubs, toilets, or on floors that are cleaned with liquid cleaners. Liquids can cause a short circuit.
- Ensure that all power cord connectors are securely and completely plugged into receptacles.
- Do not use product if power cord shows corrosion or signs of overheating.
- To prevent possible overheating, do not cover the power cord with clothing or other objects when the power cord is plugged into an electrical outlet.
- ALWAYS UNPLUG AND EMPTY the product when it is not in operation or while it is being cleaned.
- Use only clean, cool tap water when filling the tank. DO NOT use hot water.
- Never add medication of any type to the water tank.
- You should never leave the unit unattended in a closed room. The room can become saturated and leave condensation on walls and furniture. Always leave a door partially open.
- This device complies with part 18 of the FCC Rules.
- To reduce risk of fire, electric shock, or injury, place the unit and cord where it is not likely to be tipped or bumped.
- Do not overfill the water tank due to potential risk of electric shock.
- ALWAYS disconnect the product from power source before performing any maintenance or cleaning.

Safety Instructions

- Keep away from children under the age of 8 unless supervised by an adult.
- For indoor use only.
- NEVER drop or insert any object into any openings.
- DO NOT run cord under carpeting, throw rugs or runners.
- DO NOT route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
- NEVER block the air openings, grills/outlets.
- NEVER place the product on a soft surface, such as a bed or sofa, as this could cause the unit to tip over, blocking the air intake or outtake opening.
- DO NOT place anything on top of the unit.
- DO NOT expose eyes or other body parts directly to UVC light, as UVC light can be harmful to skin.
- UVC light should not be used on plants or animals, as it can cause harm.
- The UVC light is inside this product, you will not come into contact with it. The light on the top of the product is the accent light.
- DO NOT attempt to repair or adjust any electrical or mechanical functions on this unit, doing so will void your warranty.

Initial Setup

1. Remove the product from packaging and place on a sturdy, flat surface.
2. Unravel and straighten the cord before use.
3. Remove the top cover from the unit.
4. Add fresh, clean tap water to tank. Do not overfill. **Figure 1**
5. Reattach top cover.

WARNING: Never fill water tank with hot water.

Figure 1



Operation

Power On: Follow the initial setup instructions. Plug product into wall outlet. On product, press power switch to ON. Product will beep and light up as indication that it is working. Current humidity will automatically display.

Power Off: Press power switch to OFF. Empty water tank.

Refill Water Tank: See initial setup for instructions on refilling water tank. DO NOT overfill. If tank is empty, product will still run as an air purifier. Refill the tank to use the humidifier function. When tank is empty a water drop will flash 10 times on the display screen before turning red. This will disappear once the tank is refilled.

Figure 2







Figure 2

HEPA Filter: Helps purify your air. Recommended to replace every 6 months. See *Filter Replacement* for further instructions .

Permawick®: Helps purify your water. Recommended to clean or replace as needed due to environmental reasons. See *PermaWick® Cleaning* for further instructions.

Control Panel: How you operate your machine. See *Control Panel* for further instructions.

Handle: Always carry your unit by the handle.



Control Panel

On/ Off: Press button to power unit on or off.

Speed/ Sleep: By default, the machine will start running on low speed. Press the button once to run on medium speed, twice for high speed and a third time for sleep mode. **Figure 4.** The display screen will dim and the Sleep icon will appear. Press button again to turn off sleep mode and return to low speed.

UV Mode: The UV mode will automatically turn on when you power on your unit. Press the UV mode button once to turn it off. Press it again to turn it on. When UV mode is on, the icon will appear on the display screen. **Figure 4.** When UV mode is running the blue accent light will be on. This accent light is NOT the UV light, and is safe to look at.

Timer: Press button to set timer. Timer will then increase by one hour each time button is pressed, up to 12 hours. Press through all options to clear timer. Once desired time displays, the number will flash five times on the display screen to signal timer is set. The Timer icon will appear on the display screen when a timer is set. **Figure 4.** Unit will automatically shut off after the set time runs out.




Figure 3

Display Screen

Auto: Press button to have the unit run in Auto mode. The unit's running speed will be based on the room's humidity. Humidity below 40% will light up RED on the display screen and the unit will run on high speed. Humidity between 41-69% will light up GREEN on the display screen and the unit will run on medium speed. Humidity above 70% will light up ORANGE on the display screen and the unit will run on low speed. **Figure 4.** The product will try to get the room's humidity between 41-69% and adjust its speeds accordingly. Press Auto button again to turn off Auto mode. The Auto icon will appear on the display screen when Auto mode is on. Your room's current humidity level will appear on the display screen.

Filter Indicator: This icon will appear on the display screen when it is time to change your HEPA filter. **Figure 4.** It is recommended to replace the HEPA filter every 6 months, based on continuous use. However, depending on air quality and environmental factors, the filter may need to be replaced more frequently. After the filter is replaced, press and hold the filter indicator button to reset it. The unit will beep 3 times to indicate reset, and the icon will disappear off the display screen.




Figure 4

Remote Control

Using the Remote:

Your remote comes with a battery installed and does not need to be programmed. Before using your remote for the first time, you must take out the pull tab. To use remote, make sure to point it at the front of the unit. The remote will not work when pointed to the backside of the unit.

On/ Off: Press button to power product on or off.

Auto: Press once to turn on Auto mode. Press again to turn off Auto function.

Speed: There are three speed settings to choose from: low, medium and high. Press the + to increase the speed setting. Press the - to decrease the speed setting.

Timer: Timer can be set between 1 - 12 hours. Press the + to increase the timer by 1 hour each time button is pressed. Press the - to decrease the timer by 1 hour each time button is pressed. Once desired timer displays, the timer will blink five times to signal timer is set.

UV Mode: The UV mode will automatically turn on when you power on your unit. Press the UV mode button once to turn it off. Press it again to turn it on. The accent light on the top of the unit is NOT the UV light, but it will turn on when the UV light is in use.

Sleep Mode: Press once to turn off the display lights and run on the low settings. Press again to turn off sleep mode.




Figure 5

Remote Control


Replacing the Remote Control Battery:

It is recommended to replace the battery when the product takes a long time to respond or stops responding when the buttons are pressed.

1. Turn over remote control. Press the tab toward the right and pull.
2. Pull out battery holder and replace the battery. Only use the specified battery type (Lithium Button Cell Battery CR2025). The battery must be installed with the positive side facing up.
3. Insert battery holder back into remote.

Note: Do not apply excessive force to battery holder. Remove battery when not using for an extended period of time. When disposing of used battery, please use the correct method of disposal.


Figure 6



Remote Replacement:

It is recommended to store your remote on the designated spot on the top backside of the unit that reads "Remote Placement". **Figure 7**

Figure 7



	WARNING
	Keep the lithium battery out of reach of small children. Small children may accidentally swallow it. If swallowed, call your doctor immediately.

	Battery : Lithium Button Cell Battery (CR2025)
--	--

Maintenance

Note: ALWAYS unplug the unit from electrical outlet before cleaning. NEVER allow water to sit in water tank when not in use.

Hard water can cause calcium and magnesium to build up in a white powder on base of unit, transducer, and inner surface of water tank. Over time, this can cause humidifier to stop working properly.

It is recommended to clean the water tank daily, and clean the PermaWick® every 1-3 months, depending on water hardness.

Humidifier should be emptied and cleaned before storage.

Use a dry, soft cloth to dry unit after each cleaning.

Daily Maintenance:

It is recommended to refill the water tank with water every day to avoid odor from sitting water and hard water build up.

1. Turn off unit and unplug from wall outlet.
2. Remove top cover.
3. Grab handle and lift water tank out of the unit. Drain any water into a sink or tub. Shake water tank gently to remove any remaining water.
4. Rinse water tank thoroughly with water, empty, and wipe with a dry, soft cloth.
5. Wipe product base with a dry cloth if necessary.
6. Refill water tank as directed under *Initial Setup* and resume use.

Cleaning the Unit:

Hard water can cause calcium and magnesium to build up on base of unit in the form of white powder. Clean as often as needed.

1. Wipe off surface and base of unit. For best results, use a microfiber cloth.
2. Rinse surface and base with clean water.

Maintenance


Filter Maintenance:

We recommend periodically checking and replacing filters for optimal performance. Under normal conditions of continuous use the pre-filter should be replaced every 3 months (approximately 2,160 hours) and the HEPA filter should be replaced every 6 months (approximately 4,320 hours). This estimate is only a guide. Depending on air quality and environmental factors, filters may need to be replaced more regularly.

IMPORTANT: DO NOT use water, any liquid or detergents to clean the filters.

Filter Replacement:

1. Power off and unplug the product.
2. Gently take off back grille.
3. Grab the tab to remove the filter from the compartment.
4. Remove the pre-filter from the HEPA filter.
5. Align the pre-filter with the HEPA filter and firmly press to attach.
6. Put the filter back in the compartment.
7. Put the grille back into place and dispose of dirty filter.



Maintenance

PermaWick® Cleaning:

We recommend periodically checking and cleaning the PermaWick® for optimal performance. Under normal water conditions of continuous use the PermaWick® should be cleaned every 1-3 months. This estimate is only a guide. Depending on your water quality and environmental factors, the PermaWick® may need to be cleaned more regularly.

IMPORTANT: DO NOT use water, any liquid or detergents to clean the PermaWick®.

Cleaning the PermaWick®:

1. Power off and unplug the product, ensure water tank is empty.
2. Remove the top cover from the unit.
3. Grab the handle inside the tank to remove the tank. Sit it on a sturdy surface.
4. Remove the PermaWick® from the tank. **WARNING:** The PermaWick® may be saturated with water and drip when removed.
5. Rinse the PermaWick® with water and vinegar.
6. Allow the PermaWick® to air dry before placing it back inside the tank.
7. Lift the tank by the handle to place back inside the unit.
8. Place top cover on the unit and resume use.

Tank Handle






Figure 9

Top Cover



PermaWick®

Troubleshooting

Problem: Excessive Noise

Solution:

1. The water tank is not attached correctly. Properly secure water tank to base of unit.
2. The product is on an unstable surface. Place unit on a sturdy, flat surface.
3. The water tank does not have enough water. Fill water tank with water. See *Initial Setup*.

Problem: Product is not working properly

Solution:

1. The unit is not connected to power. Plug unit into a wall outlet and press the power button.
2. The water tank does not have enough water. Fill water tank with water. See *Initial Setup*.
3. The water tank has too much water. Remove excess water from tank.
4. Filter may be excessively dirty. Replace filter as needed.

Problem: Abnormal mist smell

Solution:

1. The unit is new. Remove tank cover and let water tank air out for 12 hours in a dry, cool space.
2. The water is dirty or has been sitting in unit too long. Clean water tank and add fresh, clean water. See instructions in *Maintenance*.

Problem: No mist coming from humidifier

Solution:

1. This unit uses an evaporative humidifier. Evaporative humidifiers evaporate water inside and use a fan to push water vapor out into the air that is not commonly visible.

Customer Support

Replacement Parts Ordering:

Replacement filters and wicks may be ordered online at www.hunterpureair.com or by phone by calling Hunter® Customer Support at (855) 887-1440. Applicable state and local taxes may apply. Prices are subject to change without notice.

Model #	Part #	Description
HPH625	H-PF625	Pre-Filter, 2 Pack
HPH625	H-HF625	True HEPA Photocatalyst Filter
HPH625	H-SW625	PermaWick®

Technical Support

If you need any assistance with setup, operation, or parts for your new Hunter Air Purifier/ Humidifier, please call us. Our technical support staff is ready to help!

USA/Canada: 855-887-1440
Email: info@hunterpureair.com

Hours of operation are from 8:00 AM to 6:00 PM ET, Monday through Friday. You may also contact us online at **www.hunterpureair.com**.

For all of the latest updates and promotions, follow us on our social media channels:



@hunterpureair



@hunter_pureair

Limited Warranty

Mindful, LLC makes the following limited warranty to the original residential user or consumer purchaser of the **Air Purifier/ Humidifier**: If any part of the **Air Purifier/ Humidifier** fails during two (2) years from the date of purchase due to a defect in material or workmanship, we will provide a replacement part free of charge. If no replacement part can be provided, we will replace your **product**.

IF THE ORIGINAL RESIDENTIAL USER OR CONSUMER PURCHASER CEASES TO OWN THE **AIR PURIFIER/ HUMIDIFIER**, THIS WARRANTY AND ANY IMPLIED WARRANTY WHICH THEN REMAINS IN EFFECT, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE VOIDED. THIS WARRANTY IS IN LIEU OF ALL OTHER EXPRESS WARRANTIES. THE DURATION OF ANY IMPLIED WARRANTY, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE IS EXPRESSLY LIMITED TO THE PERIOD OF THE EXPRESS WARRANTY SET FORTH ABOVE.

This warranty is voided if your **Air Purifier/ Humidifier** is not purchased and used in the USA or Canada.

This warranty excludes and does not cover defects, malfunctions, or failures of the **product** which were caused by repairs by persons not authorized by us, use of parts, or accessories not authorized by us, mishandling, possession, or unreasonable use, including failure to provide reasonable and necessary maintenance. This warranty does not cover **products** used in commercial applications. There are no express or implied warranties as to commercial purchasers or users.

See next page for more information on what is not covered.

Limited Warranty

What is not covered:

- Units that are sold “as is”, are used, or sold by unauthorized resellers (an unauthorized reseller is defined as any third-party reseller who has no official relationship with Mindful LLC.)
- Shipping or freight charges to return products for warranty service.
- Commercial or non-residential use or use inconsistent with the product instructions and manuals.
- Consumable parts (e.g., light bulbs, batteries, filters, etc.)
- Defects or damage resulting from accident, misuse, abuse, alteration, fire, floods, or acts of God.
- Cosmetic damage (e.g., scratches, dents, chips, and other damage to finishes), unless such damage results from defects in materials and workmanship and is reported within 30 days from date of delivery.
- Units with original, factory installed model numbers removed, altered, or not easily determined.
- Damage resulting from improper packing of products returned for warranty service.
- Replacement parts, repair labor costs and/or replacement of a “failed” **air purifier/ humidifier** operated outside the United States and Canada.
- Mindful LLC will have the final determination regarding who an unauthorized reseller is determined to be.

Limited Warranty

To obtain service, contact Hunter® Pure Air Customer Service at 855-887-1440. You will be responsible for insurance and freight or other transportation to our factory service center. We will return the freight prepaid. The **Air Purifier/ Humidifier** should be properly packaged to avoid damage in transit since we will not be responsible for any such damage. Proof of purchase is required when requesting warranty service. The purchaser must present sales receipt or other document that establishes proof of purchase.

IN NO EVENT SHALL **HUNTER PURE AIR** BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, CONSEQUENTIAL OR INCIDENTAL DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE **AIR PURIFIER/ HUMIDIFIER**. YOUR SOLE REMEDY WILL BE REPAIR OR REPLACEMENT AS PROVIDED ABOVE. SOME AMERICAN STATES AND CANADIAN PROVINCES DO NOT ALLOW:

- LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS;
- THE EXCLUSION OR LIMITATION OF DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES; THE EXCLUSION OR INVALIDITY OF EXPRESS OR IMPLIED WARRANTIES IF THE USER CEASES TO OWN THE **AIR PURIFIER/ HUMIDIFIER**;
- THE LIMITATION OF THE REMEDIES AND RECOURSES AVAILABLE TO THE PURCHASER; OR THE INVALIDITY OF AN EXPRESS WARRANTY WHEN A PRODUCT IDENTIFIED BY BRAND NAME IS NOT USED (UNLESS SPECIFIC CONDITIONS ARE FULFILLED); SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE OR PROVINCE TO PROVINCE.

To request warranty service, visit www.hunterpureair.com
or call (855) 887-1440