





Low Bench


1 Place the Left Arm on a soft surface with the armrest facing down. Gently insert the Seat Pan into the arm's front holes.




2 Insert the Backrest's dowels into the holes on the back of the Left Arm. Backrest should be flush to Seat Pan.




3 Gently insert the Back Strut by inserting its dowel into the remaining holes on the back of the Left Arm. Then gently attach the Right Arm by fitting the dowels into its corresponding holes.




4 Fasten the Right Arm to the Backrest, Seat Pan, and Back Strut. Then, together with a friend, gently flip the chair over, carefully keeping pieces intact and fasten Right Arm mirroring the same hardware as the Left Arm.
(A) 2x 40mm Hex Bolt, (B) 2x 55mm Hex Bolt, (C) 4x 70mm Hex Bolt




5 Fasten the Seat Pan to the Backrest with four Screws. Don't overtighten! Then, stand up the bench, take a seat— you're done!
4x Screws



Parts




1x Seat Pan




1x Backrest



1x Back Strut




1x Right Arm




1x Left Arm


Hardware



2x 40 mm Hex Bolt



2x 55 mm Hex Bolt



4x 70 mm Hex Bolt



4x Screw



1x Hex Ratchet