

COMFORT II FIRE PIT INSERT OWNER'S MANUAL



Congratulations on your purchase of our COMFORT II Fire Pit Insert! The Burly patented design and our American made craftsmanship will provide warmth for years to come. The product is designed to protect your hardscape investment and to increase your outdoor experience with a clean burning fire and reduced smoke technology. Please make sure to read the warranty, maintenance, safety and installation instructions before using your product. ENJOY!

Installation Instructions:

- 1. It is important that your fire pit is at least 15" in depth. This will allow for enough air flow underneath the fire pit insert. If the base of the insert is touching something, it could affect the air flow.
- **2.** Make sure that there is a clean surface beneath the insert.
- **3.** Next, using two people set the fire pit insert into the block/stone surround with the flange resting on the top block or cap piece.





Snuffer Lid (Included)

For Best Results:

Make sure to burn only dry, seasoned hardwood in your COMFORT II fire pit. This will ensure a hotter, cleaner fire with very little smoke. When starting your fire, use cardboard or paper with small pieces of kindling and two or three dry pieces of split hardwood on top. Always make sure that you clean out your fire pit after every 1 or 2 fires so there is proper airflow and no wet or damp ash at the bottom of your pit.

Once the fire is burning well, continue to add one log at a time as needed. Adding multiple logs on the fire at once can cool the fire down and cause more smoke. The average log should be 3-4 inches in diameter. Spread the fire out evenly and keep some hot coals against the wall of the fire pit to help with smoke reduction. You may notice a slight flex of the flange when the fire reaches high temperatures. Once the fire cools, the flange will level back out.

Note: Never fill up your fire pit with yard debris or excessive amounts of firewood as it could cause structural damage to the unit.

Maintenance:

Please try to burn a hot fire within 24-48 hours of having your fire pit insert installed. The initial burn will help the paint cure. The color of the inside walls may show imperfections where there is direct contact with the flames. This is considered normal wear and tear.

When the fire pit is not in use, the Burly team strongly recommends that you cover with the snuffer lid. Covering the fire pit will increase the life of the product by keeping moisture out, which will prevent corrosion. Do not cover the fire until the fire is completely out. Also, we suggest that you consider a custom waterproof cover to protect the entire unit.

Make sure to clean out the fire pit after every 1 or 2 fires. Cleaning out the ash will protect the unit and ensure that there is proper airflow. Do not leave ash in the bottom of the fire pit for extended periods of time.

Our fire pits can reach very high temperatures and can be exposed to all types of weather. There are no paints that can withstand direct flame contact and such outdoor use. We use the best High-Temp outdoor grill/stove paint that is rated up to 1200 degrees F. Surface rust in inevitable. Touch-up paint is available for purchase at **www.burlyusa.com**. See instructions on how to use the touch-up paint. Burly fire pits are built with heavy-duty carbon steel and state-of-the-art craftsmanship, so your fire pit will last a long time with proper maintenance.

Safety:

Burly fire pits are designed for outdoor use only. Do not set the fire pit on any type of combustible surface such as a wooden or composite deck. Set up the fire pit on a level surface when using. Do not use a flammable liquid to start your fire. Never leave you fire pit unattended and keep children a safe distance away. The outside of the fire pit can get extremely hot and cause severe burns if touched. Always wear gloves or use fire implements when making adjustments to the fire pit to avoid burns.

**Visit our website at www.burlyusa.com to learn more about our warranty

