




Conveyor Belts (FPO08)

www.multiversegamingterrain.com


Read the instructions carefully before putting the kit together. The model can be glued with PVA glue. A file and a sharp hobby knife may be needed to remove the bits of the sprue from the parts




Start by preparing these two pieces:



Glue the small walkway on top of them:




Turn the piece to the side, add the steps on both ends of it.



Raised Walkway & Angled Supports


4

For the second side pieces on both ends.



5


Put together the angled supports as shown:



Conveyor Belt


1

Start with this piece:




2

Glue these pieces on both ends of the piece as shown (the stud on top and closer to the center should be shorter)



3

Add these two pieces:



4

Add the top piece to the assembly:



Conveyor Belt


5

Add the two side pieces to the assembly:



6

Add four smaller greyboard pieces on both ends as shown and a larger one on top of the middle piece.



7


(Optional) Hide the connections with these greyboard pieces with engraved bolts:



Pillars (any height)


1

Prepare these two pieces.



2

Assemble them as shown.



3

Glue the four pillar walls together as shown, adding the pillar top piece on top.



Railings

1

To assemble the railings without the additional armor, simply push out (gently!) these three pieces out of the frame.



2

Whether you go for railing or armoured railing, add these two pieces to the module.



3

OPTIONAL: add the greyboard detailing pieces here as shown in case of the solid railings.

