

- ❶ USB-C
- ❷ USB-A 1 QC 3.0
- ❸ USB-A 2
- ❹ USB-A 3
- ❺ USB-A 4
- ❻ Power Cord Input

## Content

- PD Charging Station x 1
- Mains Lead With UK Plug x 1
- Silicon Case x 1
- User Manual x 1

## Technical Specifications


Input	100-240V ~ 50/60Hz 0.8A
Total Output	Max. 32W
Output USB-C	5V = 3A / 9V = 2.2A / 12V = 1.67A(max. 20W)
Output USB-A1 QC 3.0	5V = 3A / 9V = 2A / 12V = 1.5A; (max. 18W)
Output USB-A2+A3+A4	5V = 2.4A (max. 12W)
Output USB-C+A1	7.5W+7.5W (max. 15W)
Output USB-C+A2+A3+A4	20W+12W (max. 32W)
Output USB-A1+A2+A3+A4	18W+12W (max. 30W)

# JELLO

5 USB PD32W 1C4A

PD CHARGING STATION - UK PLUG

## How To Use



1. Connect the charger to a properly installed power socket via UK mains lead.
2. Connect your device to a USB charging socket using a suitable USB cable.
3. The charging process is displayed on your device.
4. Disconnect the device from the charger if you want to stop charging or if the device is fully charged.
5. Disconnect the charger from the mains.

## Safety Notes

- Protect the product from dirt, moisture and overheating and use it in dry rooms only.
- Do not drop the product and do not expose it to any major shocks.
- Do not operate the product outside the power limits given in the specifications.
- Do not modify the device in any way. Doing so voids the warranty.
- Do not continue to operate the device if it becomes visibly damaged.
- Use the product for its intended purpose only.
- Keep this product, as all electrical products, out of the reach of children.
- Do not use the product in the immediate vicinity of heaters or other heat sources or in direct sunlight.
- Lay all cables so that they do not pose a tripping hazard.
- Do not bend or crush the cable.
- Always pull directly on the plug when disconnecting the cable, never on the cable itself.
- Dispose of packaging material immediately according to locally applicable regulations.
- When charging batteries built into a device, pay attention to the maximum charging time for the batteries.

## Warning

- Only connect the product to a socket that has been approved for the device. The socket must be installed close to the product and easily accessible.
- Disconnect the product from the network using the power button - if this is not available, unplug the power cord from the socket.
- When using a multi-socket power strip, make sure that the sum power draw of all the connected devices does not exceed its maximum throughput rating.
- If you will not be using the product for a long period of time, disconnect it from mains power.
- Before connecting a terminal device, check whether the power output of the charger can supply sufficient power for the device.
- Ensure that the total power of all connected terminal devices does not exceed 65W.
- Please refer to the instructions in the operating manual of your terminal device.
- Do not open the device or continue to operate it if it becomes damaged.
- Do not use the product if the AC adapter, adapter cable or power cable is damaged.
- Do not attempt to service or repair the product yourself. Leave any and all service work to qualified experts.

## Warranty terms & condition

The product comes with a twelve (12) month factory warranty from the date of purchase. Your product is in perfect condition. In the event where a replacement unit is needed, the owner must provide the original receipt of purchase in order to grant replacement, providing the defect falls under warranty terms. If your unit has been disassembled or repaired without the manufacturer's authorization, the warranty will be immediately voided. The owner is responsible for any fee and charges of delivering the unit back to the agent or manufacturer.

## Explanation of Warning Symbols and Notes



This product is compliant with the CE directive.



Do not dispose of your product with other household waste. Please act according to local rules on the separate collection of electrical and electronic products and batteries. The correct disposal of these products helps prevent potentially negative consequences on the environment and human health.



This symbol indicates that the apparatus is for indoor use only.



This symbol indicates that the apparatus has a double insulation system.



This symbol indicates uninsulated material within your unit may cause an electrical shock. For safety, please do not remove product covering.



This symbol indicates direct current.



This symbol indicates attention to features for which you should read the enclosed literature closely to prevent operating and maintenance problems.