

store
away

Knighthayes
Allstore



Assembly Instructions



It is strongly recommended to have two persons present when assembling this item. We advise that you unpack the boxes in the order shown in these instructions and follow the assembly instructions carefully.

Please be careful during construction as section of the cupboard may be unstable until construction is complete.


Your hardware pack should contain the following:

 <p>CONNECTING BOLT (CB1) X 68</p>	 <p>FOLDING LEG BRACKET (FLB1) X 4</p>	 <p>TRANSFORMER (TRANS1) X 1</p>
 <p>CONNECTING LOCK (CL1) X 68</p>	 <p>WHITE CASTOR (C1) X 4</p>	 <p>PLUG (PLUG1) X 1</p>
 <p>MINI CONNECTING LOCK (CB2) X 60</p>	 <p>SCREW (CHSC-10) X 16</p>	 <p>CABLE OUTLET X 1</p>
 <p>SHELF PEG (SP1) X 136</p>	 <p>WASHER (W1) X 16</p>	 <p>BOLT (BB1) X 4</p>
 <p>BLACK CASTOR (C2) X 10</p>	 <p>ANGLE BRACKET (AB1) X 12</p>	 <p>SCREW (30-15G) X 16</p>
 <p>SCREW (S10) X 26</p>	 <p>KNOB (K1) X 2</p>	 <p>DOWEL X 45</p>
 <p>SCREW (35-17D) X 88</p>	 <p>SCREW (S30) X 2</p>	 <p>CONNECTING PLATE X 2</p>
 <p>SCREW (35-15S) X 4</p>	 <p>HINGE (H2) X 12</p>	 <p>SCREW (30-15S) X 72</p>
 <p>SHELF PEG WITH PIN (SP2) X 36</p>	 <p>SELF ADHESIVE SHELF STOP (DB1) X 25</p>	

STEP 1

You will need to open box -


SA433/190-1S



Insert CL1 Locks into the holes as indicated





Screw CB2 Bolts into all the holes marked with a red circle



screw in to this point

Screw CB1 Bolts into all the holes marked with a blue circle




- Use:
- Angle Bracket AB1
 - Screw 35-17D

STEP 2


You will need to open box -

From this box you will require panel SA433-BASE

SA433/2BCB



Insert CL1 Locks into the holes as indicated



Attach the White Castors C1 to the base using washer W1 and Screw CHSC-10 - castor locations are marked in orange

STEP 3


You will need to open box -

SA-2B

Insert CL1 Locks into the holes in the 2 panels from this box.


STEP 4

With the SA433/190LHS laying on the solid flat clean surface (we recommend the floor) attach the two back panels and the base. Secure by turning all of the connecting locks in the backs and the base approx one half turn. Then screw the remaining 35-17D screws into the angle brackets to secure the side to the base.



STEP 5

With the unit still laying on the floor place the SA433/190RHS onto the top and secure all the connecting locks and angle brackets. Then carefully stand the unit onto its wheels. **IT IS HIGHLY RECOMMENDED TO HAVE TWO PEOPLE TO COMPLETE THIS STEP TO AVOID INJURY OR DAMAGE TO THE PRODUCT.**





STEP 6

You will need to open box -

SA433/35-

TOP



screw in to
this point

Screw CB1 Bolts into all
the holes marked with
a blue circle

Place the SA433/35-TOP onto the top of the section you have already constructed and tighten the connecting locks to secure.


STEP 7

You will need to open boxes -

SA433-DS


SA190/2TCB

You will require SA-LSH from box SA190/2TCB for this step keep the other panels to one side.




STEP 8

You will require SA190-BACK from SA190/2TCB for this step.




STEP 9

You will require 2 x SA190-TCD and 2 x SA-BCD from boxes you have already opened. Ensure the centre dividers are the correct way up with the label indicating the top of the panel at the top.




STEP 10




STEP 11 - You will need to open box

You will require SA500-DESK, SA-LBAR and 2 x SA-TLEG from box SA-DESK which you may have already opened.

SA-DESK





Attach Bolts BB1 with Screws 30-15G



Add a small quantity of PVA glue into each hole marked with a red circle.


Complete this on both SA-TLEG



Attach the constructed leg section to the SA500-DESK using the Folding Leg Bracket (FLB1) and screws S10 (to fix into the brass inserts) and screws 35-15S (to fix into the pre-drilled holes)

STEP 12

Attach the complete desk to the main section using the two part hinges that are already attached to the desk and the desk shelf. The hinges can be adjusted to ensure the desk is level by turning the small adjustment screw clockwise or counter clockwise. Once in place ensure it is secured with bolts supplied.



IMPORTANT
WHEN USING THE DESK
ALWAYS MAKE SURE TO
HAVE FOLDED OUT THE
LEG BEFORE UNDOING
THE BOLT AND FOLDING
THE DESK DOWN.
FAILURE TO DO THIS MAY
RESULT IN DAMAGE TO
THE HINGES AND THE UNIT

THIS COMPLETES CONSTRUCTION OF THE
CENTRE SECTION OF YOUR UNIT

STEP 13

You will need to open box -


SA190/35

2STB

Before you start to construct this section you need to decide if you would like it to be fitted to the Left Hand side or the Right Hand side of the centre section. The standard configuration is to fit it to the Left Hand Side.



OPTION 1 - To fit to the LEFT HAND SIDE

OPTION 2 - To fit to the RIGHT HAND SIDE



STEP 14


Insert CL1 connecting locks into the SA35-TOP and the SA35-BASE as shown below. Then attach the C2 casters to the SA35-BASE using screws 35-17D as shown below.




STEP 15

With the SA35-190S1 laying on the solid flat clean surface (we recommend the floor). Attach the SA35-190S1 and SA35-190S2 to the SA35- BASE and SA35-TOP and secure by tightening the locks you have already fitted. Then fix the angle brackets to the base using screw 35-17D.

OPTION 1 - To fit to the LEFT HAND SIDE



OPTION 2 - To fit to the RIGHT HAND SIDE




STEP 16

With the Door Fascia Panel SA190-FASCIA laying on the solid flat clean surface (we recommend the floor). Attach the section that you have already assembled and secure by tightening the locks which you have already inserted into the panels.

OPTION 1 - To fit to the LEFT HAND SIDE


OPTION 2 - To fit to the RIGHT HAND SIDE



STEP 17





Using Hinge H2 and Screws 30-15S attach the completed door section to the centre section you have already constructed.



STEP 18

You will need to open:

SA190
DOOR DESK



Attach Bolts BB1 with
Screws 30-15G



Attach the SA-DLEG to the SA190-DESK56 using the Folding Leg Bracket (FLB1) and screws S10 (to fix into the brass inserts) and screws 35-15S (to fix into the pre-drilled holes)



STEP 19


You will need to open:

SA35-DS




Screw CB2 Bolts into all the holes marked with a red circle and indicated with an arrow below.

Fit the SA35-DS panel onto the CB2 bolts you have fitted and tighten the fittings to secure the shelf



STEP 20

Attach the complete desk to the door section using the two part hinges that are already attached to the desk and the desk shelf. The hinges can be adjusted to ensure the desk is level by turning the small adjustment screw clockwise or counter clockwise. Once in place ensure it is secured with bolts supplied.



IMPORTANT

**WHEN USING THE DESK
ALWAYS MAKE SURE TO
HAVE FOLDED OUT THE
LEG BEFORE UNDOING
THE BOLT AND FOLDING
THE DESK DOWN.
FAILURE TO DO THIS MAY
RESULT IN DAMAGE TO
THE HINGES AND THE UNIT**

STEP 21





You will need to open box -

SA190/35
1STB-RACK


Before you start to construct this section you need to decide if you would like it to be fitted to the Left Hand side or the Right Hand side of the centre section. The standard configuration is to fit it to the Right Hand Side.

OPTION 1 - To fit to the LEFT HAND SIDE

OPTION 2 - To fit to the RIGHT HAND SIDE




CB1




screw in to

Screw CB1 Bolts into all the holes marked with a blue circle





Use:

- Angle Bracket AB1
- Screw 35-17D



STEP 22


Insert CL1 connecting locks into the SA26-TOP and the SA26-BASE as shown below. Then attach the C2 casters to the SA26-BASE using screws 35-17D as shown below.




STEP 23

With the SA26-190SR laying on the solid flat clean surface (we recommend the floor). Attach the SA26-190S2 and SA26-190SR to the SA26- BASE and SA26-TOP and secure by tightening the locks you have already fitted to the panels. Then fix the angle brackets to the base using screw 35-17D.

OPTION 1 - To fit to the LEFT HAND SIDE



OPTION 2 - To fit to the RIGHT HAND SIDE




STEP 24

With the Door Fascia Panel SA190-FASCIA laying on the solid flat clean surface (we recommend the floor). Attach the section that you have already assembled and secure by tightening the locks which you have already inserted into the panels.

OPTION 1 - To fit to the LEFT HAND SIDE


OPTION 2 - To fit to the RIGHT HAND SIDE



STEP 25



Using Hinge H2 and Screws 30-15S attach the completed door section to the centre section you have already constructed.




STEP 26



Attach Castor C2 to SA8-BASE using 35-17D Screws



Screw CB2 Bolts into all the holes marked with a red circle



Attach the SA8 sides to the SA8-BARS and secure by tightening the locks

The fit the SA8-TOP and SA8-BASE in the same way.

Finally attach the SA8 Rack section the previous door section you constructed. Use Hinge H2 and Screw 30-15S to do this.




Add shelves and racks to this section as required. Use CB2 bolts to fix these into place.

STEP 27



Using Hinge H2 and Screws 30-15S attach the completed rack section to the door section you have already constructed.




STEP 28


Add shelves, racks and ribbon holders to the rack section you have just constructed



Shown above are a ribbon dowel and holders. To fit insert SP1 shelf pegs into the two holes in each holder and then press the holder into the side of the rack you have constructed. You can then fill the dowel with ribbon and drop onto the holders.



Fit SA8-SH Shelves to the rack as shown. Fully insert the acrylic into the shelves and then fit the rack using SP2 shelf pegs. Once the shelf is fitted on to the shelf pegs stick a shelf stop to the side of the rack right above the shelf to stop the shelf lifting off the pegs



Fit tool/stickle rack and thread racks in the same way as shelves shown above if required.

STEP 29

A standard layout of boxes is shown below. The best way to fit the boxes is to start at the bottom of each section, insert a box then add shelf pegs (SP1) and a shelf above then continue until the section is full. Use MDF shelves and SP1 shelf pegs as supplied.

The setup of shelves and boxes shown here is only one option, the shelves are adjustable to suit a range of box configurations.

Suggested box layout



store
away **Knightshayes**
Allstore

The Storeaway Knightshayes Allstore unit is designed and manufactured in the UK by:

