

COLLAPSIBLE WATER RETAINER

Keeps water inside an accessible/barrier free shower

Contact:

OLGA JARAMILLO

Phone: (310) 403-4679

olga@accessibleconstruction.com

www.AccessibleConstruction.com



All sizes and colors are available with matching **end caps**.







STRAIGHT



CURVED

Available in white and:

-  Light Tan
-  Grey
-  Charcoal
-  Dark Tan



COMPOSITION

Made from a Synthetic, Durable Plastic (Thermoplastic - TPE)

AVAILABLE SIZES

3', 4', 5', 6', 7', 8', 9'

DIMENSIONS

1 3/8" High x 1.5" Wide

COLORS

White, Grey, Charcoal, Light Tan, Dark Tan

GLUE KIT

2-in-1 Epoxy Glue Kit included with each order

ORIGIN

Made in USA

Installation Instructions

1. **Clean the area** with a cleaning solvent.

2. **Place** Water Retainer and **outline it** with **masking tape**.

3. Mix **epoxy glue**.

4. Generously **apply** to **bottom** of Water Retainer.

5. **Carefully** place the Water Retainer in **position**, pressing it so that all of the glue will be **spread out evenly** on the underside of the Water Retainer.

6. **Remove** masking tape.

7. Let **dry** for at least 24 hours



US010772471B2

United States Patent
Fine

(10) **Patent No.:** **US 10,772,471 B2**
(45) **Date of Patent:** **Sep. 15, 2020**

NOTE: If you should have a crease in the Water Retainer, it can be easily removed by heating the affected area with a blow dryer -be careful to not heat it too much as this could damage the Water Retainer. Another effective way is to leave it in the sun for a couple of hours.


www.AccessibleConstruction.com

End Cap Installation Instructions (Straight or Curved)



End Caps are to be installed on each end of the water retainer

- **Hint:** You may need to trim down one side of the Water Retainer to ensure the End Caps fit snugly next to the shower wall (Water Retainer can be easily cut down with a utility knife)
- **Clear Silicon** is recommended to install the End Caps (Not included but supplied Epoxy can be used as well)
- **Turn the End Caps upside down** and generously apply the Silicon (or supplied Epoxy) to the underside section of the End Cap that will sit on the top end of the Water Retainer
- Apply **pressure** for a few seconds once the End Cap is in place.
- **Wipe off** any excess Silicon (or supplied Epoxy)
- We recommend not using the shower for at least 24 hours until Epoxy and/or Silicon has completely dried



COLLAPSIBLE WATER RETAINER

Our patent-approved design
is made from
a very durable and unique material
(Santoprene).
This material easily collapses when a
wheelchair or foot steps on or rolls over it.



US010772471B2

United States Patent
Fine

(10) Patent No.: US 10,772,471 B2
(45) Date of Patent: Sep. 15, 2020

** Water Retainers can be installed without the end caps but typically makes a better seal at the shower walls and aesthetically looks a lot nicer**

www.AccessibleConstruction.com