
The Guide Of MAX LANTERN

AMM'FLEXIA

FLEXTAIL OL01NR02 —

Catalog

| Catalog | 01 |
|-----------------------------------|-------|
| Operation diagram | 02 |
| Parameter list | 03 |
| Instructions | 04-07 |
| After-sales service and guarantee | 08-11 |



Please read this manual carefully before using the product and keep it properly.

Parameter List

| Product name | MAX LANTERN |
|-----------------------|---|
| Product model | OL01 |
| Series | Camping lantern |
| Maximum luminous flux | 560lm |
| Maximum battery life | 23H |
| Rated power | 15W |
| Humidifying capacity | 25-40ml/H |
| Water tank capacity | 100ml |
| Charging Type | Type-C |
| Battery | 3.7V 9600mAh rechargeable lithium-ion battery |
| Operation mode | Press/Toggle |
| Size type | Medium |
| Size | L: 115.6*W: 123.7*H: 131.8mm (including the handle) |
| Material | ABS+PC |
| Weight | 490g |
| Application | Outdoor/indoor |
| Standard Accessories | MAX LANTERN (built-in battery) *1 Type-C charging cable *1 Manual *1 Storage bag *1 |

Instructions



warm and cold light adjustment:

Press twice quickly to turn on the lighting

· Power Off OFF



·Warm Mode



·Cold Mode



Bonfire Adjustment:

Toggle left and right to adjust to select bonfire mode

·Bonfire Mode

555 -Humidification Mode

OFF · Power Off



Add water tips:

Before adjusting the bonfire mode, screw the top cover counterdockwise, add pure water to below the MAX line, then screw the top cover dockwise.

Without adding pure water, dial the campfire knob, the top flame light will go out for a short time.



Battery level indicator:

In the charging state, the indicator light flashes to indicate that it is not fully charged, and the four long lights indicate that charging is complete.

Battery level indicators light up:

• • • • : 76%~100%

• • • · :51%~75% • • · · :26%~50%

○ ○ ○ ○ : 0~25%



Charging and discharging:

Open the waterproof silicone plug on charging port, and connect the power supply through the Type–C port to charge the device;



Tips:

After charging or discharging, close the waterproof silicone plug to prevent water from entering the charging port, in case unexpected failure of the device.

After-sales service and guarantee

Warranty period: 1 year

Warranty scope:

- 1, the product is within the warranty period.
- quality problems arising from the factory, such as missing original parts, damage to the film surface, etc...

Non-warranty scope:

- 1. Due to the inability to provide valid proof of original purchase (invoices or regular bills with the date of purchase and official seal of the purchase channel).
- Due to damage caused by unauthorized disassembly, modification, replace
- -ment and repair of the product without the consent of the manufacturer.
- 3. Due to human factors (human scratches, artificially caused by the fall of the super-bearing range, etc.) caused by the damage to the product.
- 4. Due to the transportation process, accidents or third parties causing damage.
 5. Damage caused by operating methods and abnormal working environment without the instruction of the product use guidelines.

Warranty service:

- Consumers can go to the Company or the Company's authorized dealers to inquire about detailed warranty services, and the after-sales staff will inform consumers of the nearest dealer's address and contact information.
- 2. If the product is covered by the warranty, the after-sales personnel will provide warranty service according to the specific situation, such as spare parts reissue or return and exchange services.
- If there is any problem related to the product, we will solve it for you in the shortest time.

Disclaimers:

1.MAX LANTERN guarantees that all products are factory inspected, if you think

there are really quality problems and omissions, please refuse to sign and contact FLEXTAIL after–sales service in time to deal with, if signed to confirm no quality defects, FLEXTAIL will not be accepted.

- The recommended use of the product such as equipment lumens and use of the environment for reference only, can not be applied to all environments, please know.
- MAX LANTERN does not support non-reasonable returns if the quality of the product itself, please understand.
- For any non-company directly published product-related statements, the company will not assume any responsibility obligations.

Paid maintenance service:

If the product you purchased exceeds the scope of the three packages service, FLEXTAIL provides you with paid repair service.

If the paid repair process is completed by repairing the defective parts, FLEXTALL will provide you with a warranty period of 30 natural days after the receipt of the repaired products; if the paid repair process is completed by replacing the defective parts with new ones, FLEXTALL will provide you with a warranty period of 90 natural days after the receipt of the new defective parts with for the pair of the pair of the pair of the pair of the pair.

- You can learn the latest repair cost standard through the official mail and other official channels.
- If the repair plan takes the form of replacement, the bad parts after replace –ment belong to FLEXTAIL.

Do not support the special circumstances of the three packages service

Does not support the return of:

- 1. the return request is made after the return time.
- The return of goods can not provide legal proof of purchase or documents, or forgery or alteration of documents.

The exchange of goods is not complete or the appearance of man-made causes of damage.

Does not support the return of:

- By MAX LANTERN internal testing, the goods themselves do not exist quality problems (only for the failure of the return class users).
- 2. Goods affecting secondary sales (including but not limited to MAX LANTERN unpacking, after the use of serious soiling, etc.).

Does not support the three packages of services:

- 1. Goods that do not meet the provisions of the three packages of services (including but not limited to exceed the deadline).
- The occurrence of man-made non-quality problems of the goods themselves resulting in collisions, burn accidents.
- Self-modification, repair or third-party disassembly, modification, repair without official authorization.
 - 4. Damage caused by the customer's own repair of the installed parts.
- Software failure of peripherals or accessories used with the goods that are not configured by the goods themselves and their failure to cause the goods.
- Damage caused by goods not operated in accordance with the commodity

 manual
- The machine serial number, factory label and other markings of the goods torn, altered signs.
- Misuse, collision, dropping, negligence, abuse, liquid ingress, moisture, accident, alteration, incorrect installation or use and other non-product quality problems resulting in the failure of the goods.
- The natural consumption, wear and tear and aging of consumable materials.
 Accessories, gifts, missing invoices or alterations affecting the integrity of the goods.
- Not in accordance with the instructions for use, maintenance and storage of goods caused by failure.

- 12. The occurrence of collision, burn, and man-made private modification, into foreign objects (water, oil, sand, etc.), incorrect installation, not in accordance with the guidelines for the use and operation of the manual caused by the quality of goods caused by the quality of rits own problems.
- Damage caused by force majeure such as accident, disaster, war, etc..
 Other cases that do not comply with MAX LANTERN after-sales policy.

Service guidelines:

- Please retain all accessories of the goods (including but not limited to accessories, gifts, warranty cards, manuals, invoices, etc.); warm tip: To ensure that your return or exchange can be carried out smoothly, we recommend that you retain the outer packaging, accessories and gifts for 30 days from the date of receipt of goods.
- 2. For exchange and repair, the goods need to be professionally tested by FLEXTAIL or FLEXTAIL's authorized repair center. After confirming the fault, FLEXTAIL company or authorized repair center will determine the corresponding repair program. If the repair program to take the replacement of the replacement of the bad parts returned to FLEXTAIL al.
- 3. Repair and replacement address: please contact customer service through the official mal and other official channels on the official website to provide you with services. In order to provide you with better after-sales service, please contact FLEXTAIL customer service before sending back the repaired or replaced goods, get the FLEXTAIL designated address and recipient, and provide the corresponding logistics bill number, so that FLEXTAIL can better track the logistics and provide after-sales service.

If you do not return the goods according to this treaty, FLEXTAIL will not be responsible.