PR AIM Mitchell Cyrus Hi-Hat (Scaffold Hi-Hat) Versatile Camera Support (THT-MTCL-01)

Assembly Manual



What's In Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

Mitchell Cyrus Hi-Hat **Setup**

• Loosen the knobs and spread it on the floor. Then tighten the knobs of Mitchell triohat again to secure appropriately.





NOTE: Be sure all knobs are tight before and after any adjustments.

If, You Detach the legs

• Loosen the knobs & Remove the 5"scaffold leg into the Mitchell mount plate.





• Similarly loosen the knobs of clamp & Remove it from their location as shown in the image





• Loosen the knobs & Remove the 5" Scaffold legs.





NOTE: You can Adjust the legs & Arms also by loosening the provided knob.





YOUR PROAIM MITCHELL TRIOHAT VERSATILE CAMERA SUPPORT ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

Liability: We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

Contact Us: In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.